

Instruction Manual

Erg max

Item# MSH112BK / MSH112BR / MSH112RD / MSH112BL

Ergonomic Mesh Chair





Purchased your product online?

We would really appreciate it if you can share your experience with others by reviewing our product on the website from which you purchased.



Have Questions or Issues? Need help with assembly? Contact us and we will resolve immediately.

Support Hours M-F 7:00AM - 3:30PM (U.S. Pacific Time)



Call: 951-319-4433



Email: customerservice@ecintel.com

Warranty

Limited 1-Year Manufacturer Warranty on ergomaxoffice.com

Manufacturer warranty covers:

- Parts that are deemed defective within 30 day will be shipped free of charge.
- Any warranty claim after 30 days, will require shipping to be paid by the customer.

Any visible damage due to the neglect, misuse, or abuse will void the limited warranty of the product.

For further information, please contact us:

Office Phone: (951) 319-4433

Email: customerservice@ecintel.com

Purchased your product online?

We would really appreciate it if you can share your experience with others by reviewing our product on the website from which you purchased.



Contents



Contents	2
What is included	3
Assembly instructions /ouTube video instruction	
	Warranty


What is included





Assembly instructions





YouTube video instruction

Please use your smart phone camera to scan the QR code. Simply point your camera and let the camera scan the code below, and click on the link that opens up.



