

WARNING!

FAILURE TO FOLLOW THESE INSTRUCTIONS AND WARNINGS COULD RESULT IN FIRE OR EXPLOSION WHICH COULD CAUSE PROPERTY DAMAGE, PERSONAL INJURY, OR DEATH.

FOR OUTDOOR USE ONLY!

ALWAYS READ AND UNDERSTAND THE OPERATION MANUAL THAT ACCOMPANIES YOUR COOKER BEFORE USING PRODUCT.

READ AND UNDERSTAND ALL OUTDOOR COOKER SAFETY PRECAUTIONS ON THE BACK OF THIS SHEET BEFORE USING PRODUCT.

ALWAYS ALLOW COOKING LIQUID TO COOL BEFORE OPERATING VALVE (BELOW 100 DEGREES F (37.8 DEGREES C)). COOKING LIQUID CAN REMAIN DANGEROUSLY HOT HOURS AFTER USE.

ALWAYS USE A THERMOMETER TO CHECK TEMPERATURE OF THE COOKING LIQUID BEFORE OPERATING THE SPIGOT.

OPERATING INSTRUCTIONS FOR SPIGOT POT:

1. Before adding cooking liquid, turn valve clockwise until it stops. This is the OFF/CLOSED position. Also make sure that the removable cap is attached and tight at the base of the spigot.
2. During use NEVER open the valve.
3. Upon completion of cooking, allow cooking liquid to cool before operating the valve (below 100 degrees F (37.8 degrees C)).
4. To operate valve, remove the cap at the base of the spigot. To open spigot, turn counter clockwise to the ON/OPEN position.

