

HOW TO PROPERLY SET UP YOUR GARDEN HOSE:

STEP 1:

To ensure maximum flexibility, initial hose setup should be performed in any spacious area, set to 70° or above.

STEP 2:

Remove all packaging and ties from the hose.


STEP 3:

Unwind the hose loosely in a circular motion before attaching it to your faucet or spigot.

NOTE: Do NOT pull the hose to uncoil it as this may cause unnecessary kinking.

STEP 4:

Attach the female end of the hose to the faucet. Allow water to run through it continuously for 2-3 minutes. Ensure that the washer is positioned correctly in the coupling.



GARDEN HOSE TIP:

Depending on your type of hose reel, the Guard-N-Grip connector can be removed off of the coupling and pulled down the length of the hose. This will guarantee an easy wind and smooth water flow once the hose is wound onto the reel.