




Replacement Parts List

Touchless Single-Handle Pull-Down Sprayer Kitchen Faucet with LED Light in Bronze

Internet #	MODEL	SKU #	FINISH
323776269	HD67536-0527H2	1009048891	Bronze



Many replacement parts can be purchased online or at your local store. Please use the table below to identify the part SKU number needed, go to [HOMEDEPOT.COM](https://www.homedepot.com), and check for online and store availability. If you can't find the part you are looking for, please call 1-855-HD-GLACIER.

Part	Description	Part #	Internet SKU #	Store SKU #
1	Spray head and Hose	RP3859927H2		
2	Wearable ring	RP70380		
3	O-ring	RP60071		
4	Cartridge	RP20044		
5	Bonnet	RP70533		
6	Cap	RP8002827H2		
7	Handle	RP1336827H2		
8	Screw	RP50015		
9	Index & O-ring	RP8044001		
10	Washer	RP64239		
11	Nut	RP56098		
12	Protective cap	RP70448		
13	Block	RP70421	207093811	
14	O-ring	RP60002		

Part	Description	Part #	Internet SKU #	Store SKU #
15	Quick connect assembly	RP70680		
16	O-ring	RP60089		
17	Weight clip	RP70590	311598800	1004610586
18	Weight	RP70689		
19	Escutcheon	RP8044127H2		
20	Bolt	RP50071		
21	Base plate	RP80442		
22	Mounting nut	RP56036		
23	Control box	RP70708		
24	Battery pack	RP70707		
25	Pump kit	RP46022		
26	Flange kit	RP4606627H2		
27	Bottle	RP46060		
28	Soap dispenser	RP4606527H2		