


Model 13742 Parts Diagram



Model 13742 Parts List

seq. NO.	appellation	qty	Material code
1	Main Lid	1	D010020237
2	Temperature Gauge	1	A0212741
3	Temperature Gauge Seat	1	D016900120
4	Main Lid Screw	2	A0407131
5	Main Lid Handle	1	D010020238
6	Hood Buffer	4	A0201340
7	Cooking Grid With Hole	1	A02120547
8	Furnace rear baffle	1	D010017328
9	BackPanel, Top	1	D010016949
10	Foot pads	4	A0206080
11	Grease Tray	1	D010017530
12	Control Knob-4#	2	A02120817
13	Control Knob Base	2	D010013934
14	Main Control Panel	1	D010017329
15	Regulator, LP	1	A02120851
16	Main Manifold	1	A02120621
17	Main Gas Valve	2	A02120566
18	Main Burner	2	A02120558
19	Clamp Spring	2	A0212873
20	Flame Tamer	2	D010016934
21	Lighting Rod	1	A02121046
22	Pressure adjusting valve hook	1	A02120823
23	LOGO	1	A0212808
	Manual	1	C043082
	Hardware Pack	1	D010017572

For assembly questions, call:
1- 800-530-9133

To make sure you obtain the correct replacement parts for your gas grill, please refer to the part numbers on this page.

Important: Keep this Owner's Manual for convenient reference and for part replacement.

Important: Use only parts listed above. When ordering parts, providing the following information:

1. Model #
2. Part Number (see PART# in chart)
3. Part Description
4. Quantity of parts needed