

ITEM #1000-000-000
MODEL #FBS80013

Tacana Wicker Chaise Use and Care Guide

Operation

1 Using the Chaise


- Always place the chaise on a hard, level surface.



WARNING: Do not rock or jump in the chaise as you may fall and cause serious injury.



WARNING: Weight capacity of this chaise lounge is 250 lbs.



Care and Cleaning

- For best results, clean the frame with damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach or solvents.
- Store the chaise in a dry, sheltered place when not in use.
- Keep the chaise out of fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

Warranty

2 YEAR WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For questions or concerns about this product contact the Customer Service Team 8 a.m. - 6 p.m. EST Monday through Friday at 1-855-HD-HAMPTON or visit www.HamptonBay.com.