

INSTRUCTIONS:

1. Remove aerator from faucet. If a wrench is necessary, place cloth over aerator to prevent damage.
2. Remove any old washers that might be caught inside the spout.
3. Clean the threads on faucet for easier installation.
4. For faucets with outside threads, remove thicker washer from fitting. For faucets with inside threads, leave thicker washer in place.
5. Install fitting onto faucet by hand.
6. Turn on faucet. If leak occurs, tighten more firmly.

INSTRUCCIONES:

1. Quite el aireador del grifo. Si se necesita una llave inglesa, coloque un trapo sobre el aireador para evitar daños.
2. Quite todas las arandelas viejas que pudieran haber quedado atrapadas dentro del surtidor de agua.
3. Limpie las rocas del grifo para una instalación más fácil.
4. Para grifos con roscas externas, quite la arandela más gruesa del conector. Para grifos con roscas internas, deje la arandela mas gruesa en su lugar.
5. Instale el conector al grifo en forma manual.
6. Abrir el grifo. Si ocurre un escape, ajuste más firmemente.