

CARGOSMART RAMPS

INSTALLATION INSTRUCTIONS


⚠ WARNING: READ AND UNDERSTAND ALL WARNINGS CONTAINED IN THE ENCLOSED USER MANUAL CAREFULLY; FAILURE TO DO SO MAY RESULT IN PRODUCT DAMAGE, PROPERTY DAMAGE AND/OR PERSONAL INJURY OR EVEN DEATH.

SAVE THESE WARNINGS FOR FUTURE REFERENCE.

- WARNING:** EXTREME CAUTION SHOULD BE USED WHEN LOADING/UNLOADING EQUIPMENT. FAILURE TO FOLLOW THESE WARNINGS AND INSTRUCTIONS MAY RESULT IN PROPERTY DAMAGE, SERIOUS BODILY INJURY, AND/OR DEATH.
- WARNING:** NEVER RIDE VEHICLE OR EQUIPMENT UP OR DOWN RAMPS. VEHICLE ENGINE SHOULD BE OFF DURING LOADING/UNLOADING.
- WARNING:** DO NOT EXCEED THE RATED CAPACITY OF THE RAMP.
- WARNING:** DO NOT LOAD VEHICLES WITH TIRES WIDER THAN RAMP.
- WARNING:** DO NOT EXCEED MAXIMUM LOADING HEIGHT OF 36 INCHES.
- WARNING:** DO NOT EXCEED THE RATED CAPACITY OF THE TRANSPORT VEHICLE OR LOAD SURFACE (TAILGATE/BUMPER).
- WARNING:** ALWAYS SECURE STRAPS TIGHTLY FROM RAMP(S) TO TRANSPORT VEHICLE TO LIMIT MOVEMENT OF THE RAMP(S) DURING LOADING/UNLOADING.
- WARNING:** ONLY USE RAMPS ON LEVEL STABLE SURFACE.
- WARNING:** NEVER STEP BETWEEN RUNGS/TREADS; THIS MAY CAUSE SERIOUS BODILY INJURY.
- WARNING:** ALWAYS CLEAN AND DRY RAMP SURFACES BEFORE LOADING/UNLOADING.
- WARNING:** KEEP BODY PARTS CLEAR OF ALL PINCH POINTS AT ALL TIMES.
- WARNING:** NEVER CUT, DRILL, WELD OR MODIFY RAMPS. ANY MODIFICATIONS TO THE RAMPS MAY CAUSE THEM TO BECOME UNSTABLE.
- WARNING:** ALWAYS INSPECT RAMPS BEFORE EACH USE. MAKE SURE THERE ARE NO BENT, BROKEN, OR WORN PARTS.
- WARNING:** RAMP FASTENERS MAY LOOSEN DURING TRANSIT AND SHOULD BE CHECKED AND TIGHTENED BEFORE USE.

BEFORE EACH USE

- INSPECT RAMP(S) AND TIE DOWNS FOR DAMAGE, FRAYING, WEAR, OR BROKEN WELDS BEFORE USE. IF DAMAGE IS PRESENT, DO NOT USE RAMP. CONTACT CARGOSMART CUSTOMER SERVICE FOR PARTS AND RECOMMENDATIONS.
- CLEAN RAMP(S) BEFORE/AFTER EACH USE, MAKE SURE TRACTION SURFACES ARE FREE OF DIRT, DEBRIS, AND OIL.
- ENSURE RAMP CAPACITY IS GREATER THAN TOTAL WEIGHT OF VEHICLE BEING LOADED/UNLOADED.
- MAKE SURE TRANSPORT VEHICLE IS PARKED WITH EMERGENCY BRAKE ENGAGED, WHEELS CHOCKED, AND ENGINE OFF.
- IF LOADING/UNLOADING ONTO A TRAILER, MAKE SURE TRAILER IS PROPERLY COUPLED TO TRANSPORT VEHICLE.



INSTRUCTIONS FOR USE

1. PLACE RAMP TOP LIP SECURELY ON LOADING SURFACE. RAMPS MAY SCRATCH LOADING SURFACE.
2. CENTER RAMP(S) ON LOADING SURFACE. WHEN USING TWO RAMPS, ALIGN THE RAMPS WITH THE CENTER OF THE WHEELS OF THE VEHICLE BEING LOADED/UNLOADED. MAKE SURE RAMPS ARE PARALLEL TO EACH OTHER AND TIE DOWN STRAPS ARE PARALLEL TO RAMPS.
3. WITH RAMPS PROPERLY SPACED AND ALIGNED, ATTACH ONE TIE DOWN STRAP TO EACH RAMP. STRAPS SHOULD BE ATTACHED TO THE CENTER OF THE THIRD RAMP RUNG/TREAD FROM THE LOADING SURFACE. ALWAYS USE TWO STRAPS ON SINGLE PIECE CONSTRUCTION WIDE FOLDING RAMPS. ATTACH THE OTHER END OF THE STRAP TO A STRUCTURAL FRAME MEMBER OF THE TRANSPORT VEHICLE. TIGHTEN ALL STRAPS AND THEN RECHECK RAMP SPACING AND ALIGNMENT.
4. CENTER LOAD BETWEEN THE SIDES OF THE RAMP.
5. WITH ENGINE OFF, SLOWLY ROLL OR WINCH EQUIPMENT UP/DOWN RAMP(S). NEVER RIDE OR DRIVE EQUIPMENT UP/DOWN RAMP(S).

FAILURE TO COMPLY WITH THIS WARNING AND THE CAPACITY LIMITATIONS MAY RESULT IN SERIOUS PERSONAL INJURY, DEATH, AND/OR SIGNIFICANT PROPERTY DAMAGE. THE ATTACHMENT/INSTALLATION OF THIS PRODUCT IS CRITICAL TO ITS LOAD CARRYING CAPABILITIES AND IS BEYOND THE CONTROL OF WINSTON PRODUCTS, LLC. IT IS THE RESPONSIBILITY OF THE USER TO UNDERSTAND THESE WARNINGS AND TO PROPERLY ATTACH/INSTALL THIS PRODUCT. WINSTON PRODUCTS, LLC IS NOT LIABLE FOR DAMAGES AND INJURIES THAT ARE THE RESULT OF IMPROPER ATTACHMENT/INSTALLATION OR IMPROPER USE.

IF YOU EXPERIENCE ANY PROBLEMS WITH YOUR CARGOSMART PRODUCT DO NOT RETURN THE UNIT TO THE RETAILER FROM WHICH IT WAS PURCHASED. INSTEAD, PLEASE CALL 1-844-295-9217 FOR ASSISTANCE WITH ANY PROBLEMS. WARRANTY INFORMATION IS AVAILABLE UPON REQUEST AND CAN BE FOUND ONLINE AT CARGOSMARTLLC.COM.