


USER MANUAL

TURBRO



Rotisserie Basket

Model: RB01



KEEP THIS USER MANUAL FOR
FUTURE REFERENCE

CONTENTS

SAFETY INSTRUCTIONS02

OPERATION TIPS03

CARING FOR THE BASKET04

WARRANTY INFORMATION05

SAFETY INSTRUCTIONS

- Read all instructions before using your rotisserie basket.
- Remove the basket and store it in a dry place when not in use.
- This basket is not for use by children.
- Do not touch hot surfaces.
- Do not use the basket for other than intended use.

WARNING:

- Always wear heat-resistant grill mitts or gloves (conforming to EN 407, Contact Heat rating level 2 or greater) when handling a hot accessory.
- Do not use your basket directly on your burner.

CAUTION: Do not set your basket on a combustible surface, glass, or a surface that can be damaged by heat.

Failure to follow these Instructions may result in serious bodily injury or may result in a fire or an explosion causing damage to property.

OPERATION TIPS

Important: Always protect your hands from hot surfaces by wearing gloves or mitts.


Cooking Preparation

1. Make sure that your basket is clean and ready to go.
2. Lightly spray or apply cooking oil to the interior surface of the grill basket to prevent food from sticking.


Assembly and Grilling Instructions

1. Place the food and desired seasonings on one side of the grill basket.

NOTE: Be careful not to overload. **Only** fill the lower section of the basket **(A)**.




2. Cover it with the other half of the basket and lock them tightly **(B)**.



OPERATION TIPS

3. Slide the spit rod through the grill basket **(C)**, tighten the thumb screws on both sides, and place it on the grill.

NOTE: Screws must touch a flat surface on the spit rod **(D)**.



Post-Cooking Safety

1. When the food is done, turn off the grill and rotisserie unit motor.
2. With heat-resistant gloves on, carefully remove the basket from the grill.
3. Place the basket in a safe and stable place to cool.

CARING FOR THE BASKET

- Clean after each use. And be sure to clean the basket **after they have cooled down to prevent scalding.**
- Soak it in hot soapy water before you clean it.
- The rotisserie basket is dishwasher safe. However, handwashing using a mild detergent with a non-abrasive nylon brush or sponge is recommended to extend the life of the product.
- Thoroughly dry before storing.
- **With usage, the color of the stainless steel surface will begin to change. This is completely normal and will not change the cooking results.**

WARRANTY INFORMATION

TURBRO provides 1-year limited warranty service for Fireside Rotisserie Accessories, from the date of purchase, subject to the following conditions and limitations.

What is covered?

- Any alteration or misuse of the product will nullify this warranty.
- This warranty is non-transferable and is effective for the original buyer from the authorized seller only.
- This warranty is limited to the repair or replacement of part (s) proved to be defective in material or workmanship after said defect is confirmed by the manufacturer's inspection.
- The manufacturer may, at its discretion, fully discharge all obligations with respect to this warranty by refunding the wholesale price of the defective part (s).

What is not covered?

- Damage caused by the owner when attempting to fix or alter the product themselves.
- Damage caused by misuse, abuse, neglect, alterations, or unauthorized repair.
- Natural depreciation.

How to request warranty services?

To obtain the benefit of this warranty please leave a message online (www.turbro.com/pages/contact-us), or send an email to **support@turbro.com**. Our customer service will address your issue within 24 hours.

What will TURBRO do?

- Replace the item.
- Refund the item under certain circumstances.

TURBRO



 support@turbro.com

 www.turbro.com