


Item # 0000 000 000
Model #FRS60744C-STC

HAMPTON BAY®

USE AND CARE GUIDE

CAMDEN POINT STEEL WICKER 3PC SECTIONAL DINING SET



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this sectional. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents	2	Corner Chair Package Contents	4
Important Safety Instructions	2	Left Arm Loveseat Package Contents	5
Save These Instructions	2	Right Arm Loveseat Package Contents	6
Read All Instructions Before Use	2	Corner Chair Assembly	7
Warranty	3	Left Arm Loveseat Assembly	9
What is covered	3	Right Arm Loveseat Assembly	11
What is not covered	3	Sectional Assembly	13
Pre-Assembly	3	Care and Cleaning	14
Planning Assembly	3		
Hardware Included	4		

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: THIS SECTIONAL IS MADE FOR THE EXPLICIT PURPOSE OF PROVIDING OUTDOOR FUNCTIONS AND IS NOT TO BE USED AS A TOY. THIS PRODUCT IS INTENDED FOR NORMAL OUTDOOR USE; HOWEVER, THE MANUFACTURER RECOMMENDS STORING AND/OR COVERING THIS PRODUCT WHEN ANY FORMIDABLE/SEVERE WEATHER IS APPROACHING.



WARNING: DO NOT LOCATE THIS PRODUCT NEAR OPEN FLAMES. DO NOT USE THIS PRODUCT AS A SUPPORT. DO NOT SHAKE, LEAN OR CLIMB ON THE PRODUCT. CHILDREN UNDER THE AGE OF 10, NEAR THE PRODUCT, SHOULD BE SUPERVISED BY A COMPETENT ADULT AT ALL TIMES. THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE AND WILL VOID THE WARRANTY.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Do not move the sectional while it is occupied. Failure to obey this caution could result in injury.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat sources.



WARNING: Weight limit for the sectional is 250lbs (102.05Kg) for each seat.



WARNING: Please keep children out of the assembly area before assembly.



WARNING: This sectional is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the sectional.

Warranty

3 YEAR FRAME AND 3 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for three years, and a three year limited warranty for the fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HAMPTONBAY.COM

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

Pre-Assembly (continued)


HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



AA



BB



CC




DD



EE

Part	Description	Quantity
AA	M6x20 Combination Bolt	19+1
BB	M6x40 Combination Bolt	10+1
CC	Metal Plate	5
DD	Metal Clip	2
EE	Hex Wrench	1


CORNER CHAIR PACKAGE CONTENTS



Part	Description	Quantity
A	Left Backrest	1
B	Right Backrest	1
C	Corner Chair Seat	1
D	Corner Chair Back Cushion	2
E	Corner Chair Seat Cushion	1

Pre-Assembly (continued)


LEFT ARM LOVESEAT PACKAGE CONTENTS



Part	Description	Quantity
F	Left Arm	1
G	Left Arm Loveseat Backrest	1
H	Left Arm Loveseat Seat	1
I	Loveseat Back Cushion	2
J	Loveseat Seat Cushion J	1
K	Loveseat Seat Cushion K	1

Pre-Assembly (continued)

RIGHT ARM LOVESEAT PACKAGE CONTENTS



Part	Description	Quantity
L	Right Arm	1
M	Right Arm Loveseat Backrest	1
N	Right Arm Loveseat Seat	1
I	Loveseat Back Cushion	2
J	Loveseat Seat Cushion J	1
K	Loveseat Seat Cushion K	1


Corner Chair Assembly

1 Attaching the Corner Chair Seat to the Right Backrest

- Place the corner chair right backrest (B) on a soft surface.
- Attach the corner chair seat (C) to the right backrest (B) using M6x20 combination bolt (AA) and M6x40 combination bolts (BB).



NOTE: Loosely tighten all the bolts using the hex wrench (EE).




2 Attaching the Corner Chair Right Backrest and Corner Chair Seat to the Left Backrest

- Attach the corner chair right backrest (B) and corner chair seat (C) to the left backrest (A) using M6x20 combination bolts (AA) and M6x40 combination bolts (BB).



NOTE: Loosely tighten all the bolts using the hex wrench (EE).




Corner Chair Assembly (continued)

3 Connecting the Left Backrest to the Right Backrest

- Connect the left backrest (A) to the right backrest (B) using M6x20 combination bolts (AA) using metal plate (CC).




NOTE: Loosely tighten all the bolts using the hex wrench (EE).



4 Tightening all Bolts

- Once all of the bolts are in place, fully tighten all the bolts.
- Turn the corner chair right side up.




Left Arm Loveseat Assembly

1 Attaching the Left Arm Loveseat Seat to the Left Arm Loveseat Backrest

- Place the left arm loveseat backrest (G) on a soft surface.
- Attach the left arm loveseat seat (H) to the left arm loveseat backrest (G) using M6x20 combination bolt (AA) and M6x40 combination bolts (BB).



NOTE: Loosely tighten all the bolts using the hex wrench (EE).




2 Attaching the Left Arm Loveseat Seat and Left Arm Loveseat Backrest to the Left Arm

- Attach the left arm loveseat seat (H) and left arm loveseat backrest (G) to the left arm (F) using M6x20 combination bolts (AA) and M6x40 combination bolt (BB).



NOTE: Loosely tighten all the bolts using the hex wrench (CC).




Left Arm Loveseat Assembly (continued)

3 Connecting the Left Arm to the Left Arm Loveseat Backrest

- Connect the left arm (F) to the left arm loveseat backrest (G) using M6 x20 combination bolts (AA) and metal plate (CC).




NOTE: Loosely tighten all the bolts using the hex wrench (EE).



4 Tightening all Bolts

- Once all of the bolts are in place, fully tighten all the bolts.
- Turn the left arm loveseat right side up.




Right Arm Loveseat Assembly

1 Attaching the Right Arm Loveseat Seat to the Right Arm Loveseat Backrest

- Place the right arm loveseat backrest (M) on a soft surface.
- Attach the right arm loveseat seat (N) to the right arm loveseat backrest (M) using M6x20 combination bolt (AA) and M6x40 combination bolts (BB).



NOTE: Loosely tighten all the bolts using the hex wrench (EE).




2 Attaching the Right Arm Loveseat Seat and Right Arm Loveseat Backrest to the Right Arm

- Attach the right arm loveseat seat (N) and right arm loveseat backrest (M) to the right arm (L) using M6x20 combination bolts (AA) and M6x40 combination bolt (BB).



NOTE: Loosely tighten all the bolts using the hex wrench (EE).




Right Arm Loveseat Assembly (continued)

3 Connecting the Right Arm to the Right Arm Loveseat Backrest

- Connect the right arm (L) to the right arm loveseat backrest (M) using M6x20 combination bolts (AA) and metal plates (CC).




NOTE: Loosely tighten all the bolts using the hex wrench (EE).



4 Tightening all Bolts


- Once all of the bolts are in place, fully tighten all the bolts.
- Turn the right arm loveseat right side up.



Sectional Assembly


1 Connecting the Left Arm Loveseat and the Right Arm Loveseat to the Corner Chair

- Connect the left arm loveseat and right arm loveseat to the corner chair using metal plate (CC) with M6x20 combination bolts (AA).
- Once all of the bolts are in place, fully tighten the bolts using the hex wrench (EE) wrench.
- Attach the left arm loveseat and right arm loveseat to the corner chair using the metal clips (DD).



2 Place the Seat Cushions and Back Cushions to the Set

- Ensure all connections are secure before use.
- Place the loveseat seat cushions J (J), loveseat seat cushions K (K), the loveseat back cushions (I), the corner chair seat cushion (E) and the corner chair back cushions (D) to the set.



Care and Cleaning

- For best results, clean the frame and fabric with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach or solvents.
- Store the sectional in a dry sheltered place when not in use.
- Keep the sectional out of fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY®

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service
8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.


For certification use only
Factory Corner Chair ID# FRS60744C Factory Left Arm Loveseat ID# FRS60744AL Factory Right Arm Loveseat ID# FRS60744BL

Item# 0000 000 000
Model # FRS60744C-STT

HAMPTON BAY®

USE CARE AND GUIDE

CAMDEN POINT STEEL ROUND DINING TABLE



Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service.
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

THANK YOU

We appreciate the trust and confidence you have placed in Hampton Bay through the purchase of this table. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Hampton Bay!

Table of Contents

Table of Contents.....	2	Pre-Assembly	3
Important Safety Instructions	2	Planning Assembly	3
Save These Instructions	2	Hardware Included	3
Read All Instructions Before Use	2	Package Contents.....	4
Warranty	3	Assembly.....	5
What is Covered	3	Care and Cleaning.....	7
What is Not Covered	3		

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: This table was as made for the explicit purpose of providing outdoor functions and is not to be used as a toy. This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this table when any formidable / severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Please keep children out of the assembly area before assembly.
4. This table is not intended to support an umbrella. Umbrellas must have a suitable base or stand.



WARNING: This table unit is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not place heavy objects on the table top.

Warranty

3 YEAR FRAME WARRANTY

WHAT IS COVERED

We warrant the frame to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HAMPTONBAY.COM.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.


HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.



AA




BB

Part	Description	Quantity
AA	M6x20 combination bolt	8+1
BB	Hex wrench	1

Pre-Assembly (continued)

PACKAGE CONTENTS



Part	Description	Quantity
A	Table top	1
B	Table leg 1	1
C	Table leg 2	2


Assembly

1 ATTACHING THE TABLE LEG 1 TO THE TABLE TOP

- Place the table top (A) upside down on a soft surface.
- Attach the table leg 1 (B) to the table top (A) using M6x20 combination bolts (AA).



NOTE: Loosely tighten all bolts using the hex wrench (BB).




Assembly (continued)

2 CONNECTING THE TABLE LEG 2 TO THE TABLE TOP AND TABLE LEG 1

- Connect the table leg 2 (C) to the table top (A) and table leg 1 (B) using M6x20 combination bolts (AA).




NOTE: Loosely tighten all bolts using the hex wrench (BB).



Assembly (continued)

3 TIGHTENING THE BOLTS

- Once all of the bolts are in place, fully tighten the bolts.
- Turn the table right side up.
- Ensure all connections are secure before use.



Care and Cleaning

- For best results, clean the table with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach, or solvents.
- Store the table in a dry, sheltered place when not in use.
- Keep the table away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY[®]

Questions, problems, missing parts? Before returning to the store,
call Hampton Bay Customer Service.
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HAMPTONBAY.COM

Retain this manual for future use.

For certification use only
Factory table ID # FTS61324B