

Register and Grille

Measurement Guide

How to Measure for Replacement Registers and Grilles

Follow these measurement instructions for a snug fit.

- Locate the register or grille you are replacing and note if it is for a wall, ceiling or floor.
- Remove the screws that hold the vent in place. Pull the vent forward and out of the opening.
- Measure the size of the air duct opening. **Do not** measure the old register or vent. Note the measurements as width and length as that is how they are packed and labeled.
- Ensure the new register or grille covers the opening. If the opening is large, look for units with wide borders.