


Rockdale Gate Assembly

Parts List

Part	Description	Qty.
A	Left Gate Panel	1
B	Right Gate Panel	1
C	Gate Posts	2
D	Ground Stakes	2
E	Gate Stakes	2
F	U-Hooks	2



Install

1. First, plan gate position and layout. Start your fence layout with gate first then build from there.
2. Measure spacing for gate post (C) location at 36-5/8 inches apart. Mark locations on ground.
3. Drive ground stakes (D) into ground with hammer. Note: Use block of wood to avoid directly striking the stakes. Fig. 1
4. Next, insert the gate posts (C) into the installed ground stakes (E). Fig. 2
5. Hang the gate panels (A&B) onto gate posts by inserting hinge pins into hinge tubes. Fig.3
6. Stake gates into closed position by installing gate stakes (E) and pushing them into the ground. You will need to lift gate stakes (E) to open gate.
7. Continue building fence by installing your fence panels. Use U-hooks (F) to attach fence panel where you find a tube to tube connection. Fig. 4

