EVERBILT ™

USE AND CARE GUIDE

WIRE PRODUCTS

Care and Cleaning

Everbilt closet organizer is powder coated. Clean following these steps:

☐ To remove dust, stains, and other deposits: Use a soft cloth (or soft brush) with a diluted solution mix of warm water and a mild detergent (such as liquid dish-washing detergent). DO NOT use solvents.

☐ Make sure you thoroughly rinse the surface(s) with clean fresh water after cleaning to remove all residue.

☐ Thoroughly dry the surface(s) before reuse.

Safety Information

☐ Please read and strictly follow the assembly instructions for proper installation. Failure to do so may cause objects to accidentally fall, which may result in personal injury or property damage.

☐ Make sure to distribute the weight evenly on each shelf and use the correct hardware for system mounting.

☐ Do not overload, which may cause collapse of the system and cause personal injury or property damage.

☐ Do not climb, stand or step on the product, which may cause collapse of the system and cause personal injury or property damage.

☐ Be sure to wear appropriate safety equipment when using power tools and hand tools.

☐ The metal may have sharp edges or corners. The use of protective gloves is strongly recommended.

☐ Recommend to protect the work surface during assembly.

☐ This product is not a toy and contains small parts which may cause choking hazard for small children. Close supervision is necessary near children.

⚠ **DANGER:** The metal may have sharp edges or corners. The use of protective gloves is strongly recommended.

⚠ **WARNING:** Do not overload the shelving units. This may cause collapse of the system and cause personal injury or property damage.

❗ **IMPORTANT:** Please read and strictly follow the assembly instructions for proper installation.

Questions, problems, missing parts? Before returning to the store,
call Everbilt Customer Service
8 a.m. – 7 p.m., EST, Monday-Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-305-1726

HOMEDEPOT.COM

Retain this manual for future use.