


PROWOOD™

6' Picnic Table Kit – ASSEMBLY INSTRUCTIONS

PARTS LIST* (Quantities may vary depending on kit).


A

1 – Tabletop




B

4 – Table Legs




C

2 – Bench Supports




D

2 – Bench Seats



E

2 – Diagonal Braces



F

8 – Hex Nuts




G

8 – Washers



H

8 – Carriage Bolts



I

32 – 2-1/2" Screws



*Your kit may include parts with beveled corners and/or preassembled legs.

BEFORE YOU BEGIN



2 PEOPLE



45 MINUTES

It will take you about 45 minutes to complete.

You'll need **two adults** to safely assemble this picnic table.



This table is made from construction grade lumber and may contain rough edges. Wear protective gear.

View our assembly video:



Mold occurs naturally on wood. If you receive a picnic table with mold on it, you can safely clean it with water and detergent or vinegar.


TOOLS YOU WILL NEED

1/2" Wrench

Power drill with #2 Phillips bit

Recommended:
Hammer, Carpenter's square, Clamp, Tape measure













ASSEMBLY


1 Insert bolts into bench supports

If your kit contains preassembled legs, skip to Step 3.

PRO TIP




Use a hammer to fully seat bolts into holes



2 Attach legs to bench supports*

* If your bench supports have beveled corners, be sure they face downward.





Do not fully tighten Hex nuts

3 Attach legs to tabletop with screws

- Center legs on tabletop

- Hold legs tight to the cleat and tabletop

- Drive in screws


PRO TIPS



- Clamp legs to cleat before drilling



- Pre-drill holes before drilling in screws



4 Attach diagonal braces with screws




Fully tighten Hex nuts before drilling the diagonal brace in place.

PRO TIP



Use a carpenter's square to confirm legs are square before drilling the diagonal brace in place.



5 Attach bench seats with screws



2 PEOPLE




Flip table up

PRO TIP



Use a tape measure to confirm bench is centered.



CARE & MAINTENANCE

PRO TIPS



Continuous water absorption and water loss in the wood can cause its natural defects to surface. To reduce the appearance of these natural defects and extend the life of your picnic table, apply a protective finish such as a semitransparent stain or waterproofing sealer.

The table has approximately 86 square feet of surface area. Apply the finish following the stain or sealer manufacturer's instructions and reapply every two years as needed.

WWW.PROWOOD.COM

THE DIAGRAMS AND INSTRUCTIONS IN THIS BROCHURE ARE FOR ILLUSTRATION PURPOSES ONLY AND ARE NOT MEANT TO REPLACE A LICENSED PROFESSIONAL. ANY CONSTRUCTION OR USE OF THE PRODUCT MUST BE IN ACCORDANCE WITH ALL LOCAL ZONING AND/OR BUILDING CODES. THE CONSUMER ASSUMES ALL RISKS AND LIABILITY ASSOCIATED WITH THE CONSTRUCTION OR USE OF THIS PRODUCT. THE CONSUMER OR CONTRACTOR SHOULD TAKE ALL NECESSARY STEPS TO ENSURE THE SAFETY OF EVERYONE INVOLVED IN THE PROJECT, INCLUDING, BUT NOT LIMITED TO, WEARING THE APPROPRIATE SAFETY EQUIPMENT. EXCEPT AS CONTAINED IN THE WRITTEN LIMITED WARRANTY, THE WARRANTOR DOES NOT PROVIDE ANY OTHER WARRANTY, EITHER EXPRESS OR IMPLIED, AND SHALL NOT BE LIABLE FOR ANY DAMAGES, INCLUDING CONSEQUENTIAL DAMAGES. FOR DETAILS ON SAFE HANDLING AND WARRANTY INFORMATION, GO TO UFPI.COM/PTINFO.

©2024 ProWood, LLC. All rights reserved. ProWood is a registered trademark of UFP Industries, Inc. Grand Rapids, MI 49525 | 1.833.577.1349

24351_12/24