

GoDear Design Products Use and Care Manual

Adjustable Sliding Panels

Daily Operation

- Use the wands on the both sides to open and close the fabric panels. Best by 45-degree angle between the wand and the panel. Apply the anti-fray clips to the leftmost and the rightmost sides of the panels in advance.
- Draw the panels in a slow and steady pace to avoid them being tangled together.

Cleaning Instructions

- Do not wash or clean the panels with wet towels since they are natural paper woven.
 - Use cleaning duster, dry towel or vacuum cleaner to clean them.
-

Zebra Roller Shades

Daily Operation

- Lower and rise the zebra roller shades from the right middle of the bottom bar. A completely center-installed lift handle is strongly recommended.
- Lower the shades straight down and avoid any tilt angle. Otherwise the shades may not stop at the position you lowered them to.

Cleaning Instructions

- Do not wash, use strong detergents, or spot removers. Dry cleaning is not recommended.
- Use slightly damp cloth to bolt gently or a vacuum with an upholstery attachment to clean your shades when dusty.
- Be careful not to wrinkle or crush the fabric when cleaning.

