Scotts

WIZZ™

YEAR-ROUND SPREADER

FEED · SEED · WEED · MELT

5FT BROADCAST
WITH THE CONTROL OF
SmartSound® TECHNOLOGY

POWERED BY
4 AA BATTERIES
*Batteries Included

See Back for More Details.
Para conocer más detalles, consulte el reverso.

HOW TO USE:

PREP



Know the size of your lawn before you begin. Be sure not to overapply.

Read and follow all directions for use and spreader settings on the label of the product that you are applying.

FILL



Set spreader over pavement when filling so any spilled product can be swept up.

SET



Turn the orange dial to correct setting corresponding to the product you are applying.

GO




Begin walking, and pull trigger to apply product. Be sure to walk at a steady pace (4 ft per second).

For a complete list of products and settings visit scotts.com/wizz Or call 1-800-543-TURF (8873)

Scotts No-Quibble Guarantee®
If for any reason you the consumer are not satisfied with the results after using this product, you are entitled to get your money back. Simply send us proof of purchase and we will mail you a refund promptly.

HOW TO APPLY:



1. Make perimeter pass with EdgeGuard® on to protect non-lawn areas.
2. Make parallel internal passes 5 ft apart to ensure even coverage.
3. Empty unused material back into product bag. Place the spreader on lawn and gently hose down to thoroughly rinse it out.
4. Do not submerge in water or allow water to sit in hopper for any length of time. Replace batteries annually.

For a how-to video visit scotts.com/wizz

Para obtener las Instrucciones de uso en español, por favor visite scotts.com/wizz o llame al 1-800-543-8873

LB24992