


CANOPY

Set-up Instructions

Trademark Innovations

Two people are needed to set up and take down the canopy. Please be very careful when setting up and taking down the canopy to avoid pinching your fingers or hands on any part of the frame. Be very careful attempting to set up or take down the canopy in windy conditions as it may fall over and cause injury.

SETTING UP THE CANOPY



1. Put the canopy in the center of the area that the canopy will cover. Take it out of the carrying bag and stand it on its feet. With someone else, lift the frame off the ground and take a step backwards.

2. The side bars of the frame will form a diamond pattern at this point. Each partner should hold onto the opposite corners (top and bottom) of this diamond and continue to walk backwards until the canopy is completely open. Do not use excessive force when opening up the frame or you will bend the support poles.






3. While holding down the top of the tent leg with one hand, push up with the other hand. There is a snap button inside that will lock into a hole on the outside of the leg when the leg is fully extended. Do the same with the other 3 legs.

4. You and the other person should both place a foot on the bottom of two legs next to each other, and lift up the legs. Slide the legs out until the snap buttons lock into place. Repeat the procedure for the other two legs.

5. Attach the Velcro pieces on the bottom side of the canopy cover to the Velcro pieces on the frame.

6. Using the supplied guy wires and stakes, stake the canopy to the ground or just drive the stakes through the holes in the frame's feet.

TAKING DOWN THE CANOPY



1.Remove any stakes and/or guy wires that are holding the canopy to the ground. Undo the Velcro where the canopy top is attached to the frame.

2.You and another person should each lift up 2 adjacent legs of the canopy slightly, push down the lock button and collapse the legs. Repeat this procedure for the other two legs.

3.Release the sliders at the corners. Do this by applying slight upward pressure with one hand while at the same time pushing the lock button with the other. Push the slider past the lock button.

4.The frame will at this point form a diamond pattern. Each person should hold onto opposite corners (top and bottom) of this diamond and pick up the canopy. Each partner should walk towards each other while pulling their hands apart. This will cause the frame to close up.

5.Hold the two outer legs. Lift the frame off the ground and push the legs together, and this will cause the frame to close.

Always be sure to air out the canopy tent cover and let it dry out before putting it away, this will prevent mold and mildew.

We hope that you are satisfied with the canopy and that it is meeting your expectations.

If there are any parts missing from the canopy or it is defective in any way,
please feel free to contact us at
1-800-906-1639.