



Model XWT16Z Parts List

Item#	Part#	Description	Q'ty
001	266130-9	TAPPING SCREW BIND PT 3X16	8
002	191K96-9	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2
	C20 252126-6	HEX. LOCK NUT M4-7	2
	C30 8012S6-4	CAUTION LABEL	1
	D10	INC. 37	
003	268284-8	PIN 1.5	1
004	263036-2	RUBBER PIN 5	1
005	811V28-3	XWT16 NAME PLATE	1
006	422584-2	BUMPER	1
007	412556-5	HAMMER CASE COVER	1
008	141E94-7	HAMMER CASE COMPLETE	1
009	265472-8	HEX. SOCKET HEAD BOLT M4X25	4
010	261171-0	NYLON WASHER	1
011	233943-3	RING SPRING 8	1
012	213960-9	O RING 5	1
013	136510-2	ANVIL ASS'Y	1
	D10	INC. 11,12	
014	327892-5	HAMMER	1
015	216001-0	STEEL BALL 3.5	24
016	267175-0	FLAT WASHER 24	1
017	234322-8	COMPRESSION SPRING 25	1
018	216011-7	STEEL BALL 5.6	2
019	227338-0	SPUR GEAR 22	3
020	327573-1	SPINDLE	1
021	268311-1	PIN 5	3
022	233910-8	RING SPRING 43	1
023	227337-2	INTERNAL GEAR 51	1
024	213785-1	O-RING 49	1
025	140T37-6	INTERNAL GEAR CASE COMPLETE	1
026	266490-9	TAPPING SCREW PT 2X6	3
027	652069-6	FLAT HEAD SCREW M3X6	3
028-	629A98-0	STATOR	1
029	620C64-2	CONTROLLER	1
030	619626-3	ROTOR	1
031	412691-9	REAR COVER	1
032	266130-9	TAPPING SCREW BIND PT 3X16	2
033	620521-2	LED CIRCUIT	1
034	455053-8	F/R CHANGE LEVER	1
035	651443-5	SWITCH C3JR-4B	1
036	140T43-1	SWITCH PLATE COMPLETE	1
	C10 8012S9-8	SWITCH LABEL	1
037	191K96-9	HOUSING SET	1
	C10 263005-3	RUBBER PIN 6	2
	C20 252126-6	HEX. LOCK NUT M4-7	2
	C30 8012S6-4	CAUTION LABEL	1
	D10	INC. 2	
038	424517-3	CUSHION	1
039	643874-2	TERMINAL	1
040	811V32-2	XWT16 SERIAL NO. LABEL	1
A01	266622-8	+ TRUSS HEAD SCREW M4X12	1
A02	346449-3	HOOK	1