


T-fal®

AVANTE



Instructions for use Mode d'emploi Modo de empleo

T-FAL a division of GROUPE SEB USA 2121 Eden Road Millville, NJ 08332
GROUPE SEB CANADA, 345 Passmore Avenue, Toronto, ON M1V 3N8
Groupe SEB MEXICO S.A. de C.V. Goldsmith 38 Desp. 401 Col. Polanco
Delegacion Miguel Hidalgo 11 560 Mexico D.F. MEXICO

Réf. NC00025630 • 10/2011
Subject to modifications
Soumis à modifications

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock do not immerse cord, plugs, or this appliance in water or other liquid.
4. Not intended for use by children. Close supervision is necessary for any appliance being used near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. To shut down the appliance, turn any control to "off," then remove plug from wall outlet.
12. Do not use appliance for other than intended use.
13. Oversize foods, metal foil packages, or utensils must not be inserted in a toaster as they may involve a risk of fire or electric shock.
14. A fire may occur if toasters are covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
15. Do not attempt to dislodge food when toaster is plugged in.

SAVE THESE INSTRUCTIONS.

ENVIRONMENTAL PROTECTION

The packaging of your product is made of recyclable materials. Do not throw it out with your usual garbage; take advantage of your local recycling program.

DO

- The toaster must always be used in the upright position (not on its side or tilted forward or back).
- Before each use, make sure that the crumb tray is in its proper location.
- Regularly remove crumbs from crumb tray.
- The control lever must be in the "Up" position before attaching or disconnecting the plug from wall outlet.
- If bread jams in the slots after toasting, the unit will automatically shut off. Disconnect the plug immediately from the wall outlet and wait for the appliance to cool before attempting to remove the bread.
- Disconnect the appliance if it shows any working abnormalities.

DO NOT

- Never leave the toaster unattended during operation.
 - Do not touch the metal parts or hot surfaces of the appliance when it is working or before it has cooled.
 - Do not try to toast bread that may melt (with icing) or drip in the toaster and do not toast crusts as this may damage the appliance or cause a fire.
 - Do not try to toast very thick slices of bread that could block the toasting mechanism.
 - Bread can burn; do not cover this appliance while in use and do not use this appliance near any flammable materials such as curtains, under shelving or wall cupboards, etc. It should be attended to when in use.
 - Do not put paper towels, cardboard or plastic in, on or under the toaster.
 - If flames were to arise from parts of the toaster, never attempt to extinguish them with water. Unplug the appliance and smother the flames with a damp cloth.
 - Do not use this appliance as source of heating or drying.
 - Do not use the toaster for cooking, grilling or defrosting frozen food other than bread products.
 - Do not unplug appliance by pulling on cord. Instead grasp plug and pull to disconnect.
 - Never wrap cord around toaster. Use cord storage on the underside of unit.
 - Do not immerse toaster in water or run water into the toaster.
 - Do not operate toaster under or around any flammable materials, such as curtains, or under cabinets.
 - Do not place the toaster in the dishwasher.
 - Do not cover toast chambers when in use.
 - Do not insert objects into the toaster.
 - Do not use abrasive cleaners, metallic utensils or scouring pads.
- This product has been designed for household use only. Any professional use, inappropriate use or failure to comply with the instructions will void the warranty.

FOR HOUSEHOLD USE ONLY

SAFETY INSTRUCTIONS

For your safety, this appliance complies with applicable technical rules and norms. Do not place under cabinet or flammable items such as curtains. Voltage on appliance must comply with voltage in your home. Use a stable work surface, away from any contact with water and never in a built-in kitchen alcove. Do not move the appliance when working.

POLARIZATION INSTRUCTIONS

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

SHORT CORD

- a. A short power-supply cord (or detachable power-supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord.
- b. Longer detachable power-supply cords or extension cords are available and may be used if care is exercised in their use.
- c. If a long detachable power-supply cord or extension cord is used,
 - 1) The marked electrical rating of the cord or extension cord should be at least as great as the electrical rating of the appliance, and
 - 2) The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

MANUFACTURER'S WARRANTY

 www.t-fal.com

With a strong commitment to the environment, most of T-fal products are repairable during and after the warranty period. Before returning any defective products to the point of purchase, please call T-fal consumer service directly at the phone number below for repair options.

Your help to sustain the environment is appreciated!

The Warranty

This product is guaranteed by T-fal for 1 year against any manufacturing defect in materials or workmanship, starting from the initial date of purchase.

The manufacturer's warranty by T-fal is an extra benefit which does not affect consumer's Statutory Rights.

The T-fal warranty covers all costs related to restoring the proven defective product so that it conforms to its original specifications, through the repair or replacement of any defective part and the necessary labor. At T-fal's choice, a replacement product may be provided instead of repairing a defective product. T-fal's sole obligation and your exclusive resolution under this warranty are limited to such repair or replacement.

Conditions & Exclusions

The T-fal warranty only applies within USA, Canada & Mexico, and is valid only on presentation of a proof of purchase. The product can be taken directly in person to an authorized service centre or must be adequately packaged and returned, by recorded delivery (or equivalent method of postage), to a T-fal authorized service centre. Full address details for each country's authorized service centre are listed on the T-fal website (www.t-fal.com) or by calling the appropriate telephone number listed below to request the appropriate postal address.

T-fal shall not be obligated to repair or replace any product which is not accompanied by a valid proof of purchase.

This warranty will not cover any damage which could occur as a result of misuse, negligence, failure to follow T-fal instructions, use on current or voltage other than as stamped on the product, or a modification or unauthorized repair of the product. It also does not cover normal tear and wear, maintenance or replacement of consumable parts, and the following:

-using the wrong type of water or consumable

- scaling (any de-scaling must be carried out according to the instructions for use);
- immersion in water, or infiltration of dust, or insects into the product;
- mechanical damages, overloading
- damages or bad results due to wrong voltage or frequency
- accidents including fire, flood, lightning, etc
- professional or commercial use
- damage to any glass or porcelain ware in the product

This warranty does not apply to any product that has been tampered with, or to damages incurred through improper use and care, faulty packaging by the owner or mishandling by any carrier.

The T-fal manufacturer's warranty applies only for products purchased and used in USA, Canada & Mexico. Where a product purchased in one country and then used in another one:

- a) The T-fal guarantee duration is the one in the country of usage of the product, even if the product was purchased in another listed country with different guarantee duration.
- b) The T-fal guarantee does not apply in case of non conformity of the purchased product with the local standards, such as voltage, frequency, power plugs, or other local technical specifications
- c) The repair process for products purchased outside the country of use may require a longer time if the product is not locally sold by T-fal
- d) In cases where the product is not repairable in the new country, the T-fal guarantee is limited to a replacement by a similar product or an alternative product at similar cost, where possible.

Consumer Statutory Rights

This T-fal manufacturer's warranty does not affect the statutory rights a consumer may have or those rights that cannot be excluded or limited, nor rights against the retailer from which the consumer purchased the product. This warranty gives a consumer specific legal rights, and the consumer may also have other legal rights which vary from State to State or Country to Country or Province to Province. The consumer may assert any such rights at his sole discretion.

Additional information

Accessories, Consumables and end-user replaceable parts can be purchased, if locally available, as described in T-fal internet site.

CANADA

GROUPE SEB CANADA
345 Passmore Avenue
Toronto, ON
M1V 3N8
1-800-418-3325

MEXICO

Groupe SEB MEXICO S.A. de C.V.
Goldsmith 38 Desp. 401 Col. Polanco
Delegacion Miguel Hidalgo
11 560 Mexico D.F. MEXICO
(01800) 112 83 25

U.S.A.

GROUPE SEB USA
2121 Eden Road
Millville, NJ 08332
800-526-5377

 www.t-fal.com