








Assembly Instructions

Caution : You must read this before you proceed





Recliner Chair



Parts List


Label	Picture	Description	QTY
A		Chair Backrest	1
B1		Right Wing	1
B2		Left Wing	1
C		Chair Base	1
D		Front Leg	2
E		Hind Leg	2

Hardware

Label	Picture	Description	QTY
1		Gasket	7
2		Washer	3
3		Allen Key	1
4		Bolt (M6*40mm)	3

Assembly Preparation

Before Beginning Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Parts Introduction




This Recliner Chair has multiple parts and may require up to some 20 minutes to assemble. To give you an overview of the Recliner Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise the parts and steps before assembly.

Step 1



Place the Chair Base (C) on a clean, non-marring surface.
Lay Chair Backrest (A) and inner box aside.
Open the inner box and take out the Four Legs and hardware.

Step 2




Then, turn the Chair Base (C) upside down on a clean, non-marring surface. Extend the Footrest to open.

Carefully take out inner box stowed as shown above.

Open it, and you will find Wings (B1) & (B2).

Stow the Footrest to original position.

Step 3



Keep the Chair Base in the same position, first, install the Front Leg (D) at the bottom of the Chair by placing one Gasket (1) on the threaded stem. Then insert threaded stem into the threaded mounting position at the corner of the chair.


Tighten by turning the leg clockwise, DO NOT OVER TIGHT.

Repeat the same step to install the remaining three Legs (D) & (E).

Take care of the shape of the Legs and ensure they are in the correct positions.


Note: The use of the Gaskets are OPTIONAL and are especially useful to help alleviate slight wobbleness. Some legs may need more than one gasket whilst some legs may not need any.

Step 4




Position the Chair Backrest(A) on it's right side.
Align the mounting positions of the Left Wing(B2) with left side of Chair Backrest (A).
Then slide Left Wing(B2) forward by hand to make sure it locks into the position as shown in the picture.

Step 5




Attach Left Wing(B2) to the Chair Backrest(A) using Bolts(4) and Washer(2) with Allen Key(3).
Fully tighten it until secure.

Step 6



Repeat Step 4 and Step 5 to attach Right Wing(B1) to the right side of the Chair Backrest(A).


Step 7



With assistance from your adult partner, hold up the fully assembled backrest with Wings, stand behind the chair. Insert the small metal arms on the sides of the Chair Backrest into the prefabricated slide lock gadget on the Chair Base as shown above.

Firmly but gently, push the Chair Backrest downwards until the **Backrest is fully slotted and locked into position.**


Step 8



Smooth down the fabric flap on the Chair Backrest.


Run your hands down both sides of the flap, from top to bottom, allowing the velcro tape to adhere to the flap under the seat of the chair.

Step 9



Make sure all parts are connected and securely locked into position.
Your Chair is ready for use.

Step 10



Disassembly Note: Open the flap on the Chair Backrest(A), use a screwdriver (Don't use fingers) pressing outward on the metal ear on the preattached Metal Bracket on one side of the Chair Base(C), with assistance of you adult partner to keep the Chair Base(C) in place, pull out the Chair Backrest(A) upward at the same time, repeat the same step for another side. Then the Chair Backrest(A) can be taken out.

User Instructions.

Recliner Chair


Please read the Instruction Manual below carefully before use.

This is a Recliner Chair. At anytime in a reclined seat position or in the upright position. You may enjoy the rocking motion by using your body weight in a back-front rocking motion.

Supervise children, when in use of this Recliner.

To get into a reclined posture - To Recline backrest

Sit into the seat.
Place your feet apart .
Place your left and right arm onto the armrest.
Synchronise a backward push with your arms.
Use your body weight and push backwards into the seat into a fully reclined position.













To get out of chair - move Seatback into Upright Position

Tilt your body weight slightly forward and upwards.
The seat back will come up to an upright position.
Where necessary, use either your arms help lift- push yourself out of the seat.



Care & Maintenance

-  Do not put hot items directly on furniture surface
 -  Do not clean furniture with harsh cleansers or polish.
 -  Do not place furniture under direct sunlight.
 -  Do not place furniture near heating or cooling vents.
 -  Do not write on furniture without a padded barrier to protect the surface.
 -  Do not place furniture outside . For indoor use only .
 -  Not for commercial use. For residential use only .
 -  Stains may be removed with mild soap solution and damp cloth.
 -  Children should not climb or jump on the furniture.
-
-  Dust and pick-up spills using a clean, non-colored, lint-free cloth .