




CHIMNEY CAP



※ Hahaemall Hint

Hi, don't let the assembly details dissuade you. Just be patient and methodical during the assembly and you will be very pleased with the results. Hope this installation manual will help you a lot. Any problem, just contact us to **ushahaemall@outlook.com**.


WARNING

- Failure to wear proper safety gear (i.e., eye protection) may result in serious injury or death.
- Always wear proper safety gear before using power tools.
- Improper operation of power tools may result in loss of control, serious injury or death.
- Always ensure you have complete control of the power tool and the work area is free
- Take safety measures for high-altitude operations, please wear protective equipment, and be careful not to fall from a height
- It is recommended to carry out installation work in weather without wind, rain or snow
- Please wear non slip shoes during installation to prevent slipping from a height above the roof
- Please wear gloves during installation to prevent equipment from scratching your hands


MAINTENANCE

- It is recommended to regularly check the tightness of the screws to prevent the product from loosening from the chimney
- Regular painting can be done to prevent rusting and extend the service life of the product

STEP 1 / Install the 4 side panels with I bolts



STEP 2 / Install the top cover with I bolts




Two installation methods

Top fixed or Side fixed

(You can choose the appropriate installation method based on the size and shape of the chimney)


Top fixed:

STEP 3 / Install the C and B bezel with I bolts




STEP 4 / Install the Chimney cap on your Chimney

Notice: Drill holes at the corresponding positions on the top of the chimney, insert expansion tube, then install the Chimney cap with H screws.




Side fixed:

STEP 3 / Install the D and B bezel with I bolts



STEP 4 / Install the Chimney cap on your Chimney

Notice: Secure the product around the chimney with G screws



Chimney Cap Package Includes

A	1 PC	B1	2 PC	B2	2 PC
C1	2 PC	C2	2 PC	D1	2 PC
D2	2 PC	E	1 PC	F	1 PC
G	8+1 PC	H	8+1 PC		
				I	
				10x19"	
				13x17"	
				10x14"	
				13x21"	
				13x24"	
				32+5PSC	
				36+5PCS	