


Please read and retain these instructions for future reference



Parts List:






Please read and retain these instructions for future reference

Assembly Instructions:

- Place all the pieces on the floor.
- Connect the Crossbar (Part 3) with the Bases (Parts 5).
- Screw the bolts tightly into place. (1)
- Connect the Hammock Frame Bar (Part 4) with the Bases (Part 5).
- Screw the bolts tightly into place.
- Put the hook and washer in the appropriate hole to suit Hammock size.
- Screw the wing nut to fix the hook. (2)
- Hang the Hammock, the Hammock should only have a slight curve when first fitted to accommodate the body weight. Adjust as hammock stretches.



WARNINGS / CAUTIONS:

- It requires at least 2 people to assemble the Hammock. Do NOT attempt to assemble the Hammock on your own.
- Assemble on a firm, flat surface.
- Keep away from fires or heat sources.
- Once assembled, do NOT put any objects directly underneath, in front of or behind the Hammock.
- Only for use on a level surface.
- Maximum weight limit: 120Kgs
- This is NOT a toy. Do NOT let children play with the Hammock or play around it when it is in use.
- Do NOT swing excessively in the Hammock as this may cause the Hammock to become unstable.
- Do NOT smoke while using the Hammock.
- Do NOT use when under the influence of alcohol or drugs.
- Before every use, check that all fastenings are secure.
- Store in a cool, dry place when not in use.
- Do NOT allow to get wet.
- Do NOT use in windy conditions.
- Take care when getting in and out of the Hammock.
- Sudden movements may cause the Hammock to swing erratically.

CLEANING INSTRUCTIONS: Wipe over with a damp cloth.

DISPOSAL:

- Dispose of all packaging, paper, cartons and plastic, plastic bags in accordance with your local recycling regulations.
- At the end of the product's lifespan please dispose of it at an authorised household waste recycling centre.