


ELECTRIC PRESSURE WASHER




WESTINGHOUSE OUTDOOR POWER EQUIPMENT

777 Manor Park Drive, Columbus, OH 43228 • WestinghousePortablePower.com

If you have questions or need assistance, please call customer service at 855-944-3571.

WPX2700e/WPX3200e Exploded View A Pressure Washer



WPX2700e/WPX3200e Parts List A (Pressure Washer)

No.	Description	Part Num.
1	Spray Gun	01000263-0
2	Lance	03000274-0
3	Cord Retainer	02000463-0
4	Turbo Nozzle	03000313-0
5	Bolt (M6 x 45 mm)	04000405-0
6	Inlet Filter	04000267-0
7	Upper Handle	03000276-0
8	Screw (M6 x 25 mm)	04000406-0
9	Gun Holster	02000462-0
10	Wheel	02000459-0

No.	Description	Part Num.
11	Hose Retainer	02000460-0
12	Axle	03000279-0
13	Washer	03000299-0
14	Hitch Pin	04000392-0
15	0° Nozzle	03000310-0
16	15° Nozzle	03000327-0
17	25° Nozzle	03000309-0
18	Soap Nozzle	04000388-0
19	O-Ring Replacement Kit	04000137-0
20	High Pressure Hose	02000482-0