






Product Listing


Shaker Satin White

Wall Cabinets (12"D unless noted)			Model #	Internet #
	30"H	9"W	KW930-SSW	205390932
		12"W	KW1230-SSW	204637901
		15"W	KW1530-SSW	204637902
		18"W	KW1830-SSW	204640134
		21"W	KW2130-SSW	205390910
		24"W	KW2430-SSW	204640135
	36"H	9"W	KW936-SSW	205390866
		12"W	KW1236-SSW	205390904
		15"W	KW1536-SSW	205390953
		18"W	KW1836-SSW	205390936
		21"W	KW2136-SSW	205390956
		24"W	KW2436-SSW	205390959
42"H	12"W	KW1242-SSW	205390885	
	15"W	KW1542-SSW	205390908	
	18"W	KW1842-SSW	205390909	
	24"W	KW2442-SSW	205390907	
	30"H	27"W	KW2730-SSW	205390884
		30"W	KW3030-SSW	204640136
		36"W	KW3630-SSW	204640137
	36"H	27"W	KW2736-SSW	205390962
		30"W	KW3036-SSW	205390935
		36"W	KW3636-SSW	205390853
	42"H	30"W	KW3042-SSW	205390905
		36"W	KW3642-SSW	205390933
Corner Wall (Installs in 24" x 24" wall area)				
	30"H	24"W	KWD2430-SSW	204640269
	36"H	24"W	KWD2436-SSW	205390911
	42"H	24"W	KWD2442-SSW	205390880
Wall Bridge				
	12"H	30"W	KW3012-SSW	204640266
		36"W	KW3612-SSW	204640267
	15"H	30"W	KW3015-SSW	205390882
		36"W	KW3615-SSW	205390957
	18"H	30"W	KW3018-SSW	204640268
		36"W	KW3618-SSW	205390958
	23-1/2"H	30"W	KW3024-SSW	205390886
		30"W x 15"D	KW302415-SSW	205390906
		36"W	KW3624-SSW	205390867
Wall Flex				
	30"H	18"W	KWFC1830-SW	205334569
	18"H	30"W	KWFC3018-SW	205334523
Wall Flex Shelf – Ready to Assemble				
	13 3/8"H	48"W	KWMS4813-SW	301345723



Product Listing






Shaker Satin White

Base Cabinets (34-1/2"H x 24"D unless noted)		Model #	Internet #
	9"W	KBF09-SSW	205390934
	12"W	KB12-SSW	204610519
	15"W	KB15-SSW	204610520
	18"W	KB18-SSW	204610521
	21"W	KB21-SSW	205390879
	24"W	KB24-SSW	204610522
	27"W	KB27-SSW	205390960
	30"W	KB30-SSW	204635906
	36"W	KB36-SSW	204635907
Waste Bin Base - includes a 12 gallon trash can			
	18"W	KBW18-SSW	301357970
Drawer Base			
	18"W	KDB18-SSW	204635908
	24"W	KDB24-SSW	205390914
Pots & Pans Drawer Base			
	30"W	KDB30-SSW	301358154
	36"W	KDB36-SSW	301358150
Sink/Cooktop Base			
	30"W	KSB30-SSW	205390954
	36"W	KSB36-SSW	204635909
Apron Front Sink Base			
	36"W	KSBD36-SSW	301348010
Accessible Sink Base			
	36"W	KSBA36-SSW	205390881
Corner Sink Base - Ready to Assemble			
	36"W	KCSB36-SSW	205390937
Blind Base			
	36"W	KBBC45-SSW	205390883
Corner Base with Lazy Susan (Installs in a 36" x 36" wall area)			
		KBLS36-SSW	204637899



Product Listing

Shaker Satin White

Specialty Cabinets		Model #		Internet #
Pantry (18"W) (Minor assembly of toe kick is required on 96"H pantry)				
	84"H		KP1884-SSW	204637900
	90"H		KP1890-SSW	205390961
	96"H		KP1896-SSW	205390878
Double Oven				
	84"H	33"W	KDV3384-SSW	301347995
	90"H	33"W	KDV3390-SSW	301348000
	96"H	33"W	KDV3396-SSW	301347998
Refrigerator End Panel Kit (Deep Bridge Cabinet must be ordered separately)				
	84"H	24"D	KAREP-SSW	301348021
Deep Bridge Cabinet (24"D) To be used with Refrigerator End Panel				
	12"H	36"W	KW361224-SSW	301347997
	18"H	36"W	KW361824-SSW	301345719
	24"H	36"W	KW362424-SSW	301348019
Vanity Cabinets (21"D)				
Vanity Drawer Base				
	34 1/2"H	12"W	KVDB12-SSW	301357990
Vanity Base				
	34 1/2"H	24"W	KVSB24-SSW	301357974
	34 1/2"H	30"W	KVSB30-SSW	301357986
	34 1/2"H	36"W	KVSB36-SSW	301358141



Product Listing

Shaker Satin White

Accessories	Model #	Internet #
End Panels		
Wall Veneer 30"H (2/pack)	KAS1230-SW	202266821
Wall Veneer 36"H (2/pack)	KAS1236-SW	205437704
Wall Veneer 42"H (2/pack)	KAS1242-SW	205437711
Base Veneer (2/pack)	KAS2435-SW	202266825
Island/Peninsula Panel 48"W	KAIE4835X-SW	205437718
Dishwasher End Panel	KADEP-SW	202266817
Universal Panel 48" x 11-1/4"	KAUP1148-SW	205437724
Universal Panel 60" x 12"	KAUP1260-SW	205437731
Decorative End Panels		
Decorative Wall 12"W x 30"H	KAEP1230-SSW	205437695
Decorative Wall 15"W x 30"H	KAEP1530-SSW	301345737
Decorative Wall 18"W x 30"H	KAEP1830-SSW	301348008
Decorative Wall 12"W x 36"H	KAEP1236-SSW	205437696
Decorative Wall 12"W x 42"H	KAEP1242-SSW	205437697
Decorative Base 24"W x 30"H	KAEP2430-SSW	205437698
Fillers		
3"W x 30"H	KAFS330-SW	100533083
6"W x 30"H	KAFS630X-SW	205437737
3"W x 36"H	KAFS336X-SW	205437743
6"W x 36"H	KAFS636X-SW	205437749
3"W x 42"H	KAFS342X-SW	205437755
6"W x 42"H	KAFS642X-SW	205437763
3"W x 91-1/2"H	KAFS396-SW	100535874
Drawers and Moldings		
Pull-Out Drawer for 24" Base	KADWR24	202518698
Pull-Out Drawer for 30" Base	KADWR30	202518766
! Toe Kick Molding 91-1/2"L	KATKX-SW	100544050
Shoe Trim Molding 91-1/2"L	KAMTX-SW	205824463
Scribe Molding 91-1/2"L	KAMS-SW	100535879
Traditional Crown Molding 91-1/2"L	KAMC5-SW	100539084
Shaker Crown Molding 91-1/2"L	KAMC4-SW	204651949
Base Molding 91-1/2"L	KAMBSX-SW	205437772
Outside Corner Molding 91-1/2"L	KAOCMX-SW	205437788
Square Edge Molding 91-1/2"L	KAMSQX-SW	205437797
Decorative Edge Molding 91-1/2"L	KAMDEX-SW	205437803
Decorative Accessories		
Decorative Island Panel Kit	KADPK337-SW	205437809
Decorative Corner Post	KADCP6-SW	205437816

†Satin White panels are laminate

! Indicates required accessory to complete your project

Dimensions are rounded and are provided for general guidance only. For proper installation on all Hampton Bay products, refer to instructions printed on product carton. The manufacturer reserves the right to discontinue the sale or change the specifications of any product at any time. Every effort was made to assure accuracy of the information contained herein at the time of printing, however, the manufacturer makes no representations to such accuracies.



- Start with the first wall on the left and work to your right around the room. Measure the overall length of each wall.
- Indicate breaks in walls (windows, doors, closets) by measuring to the outside edge of the molding. Include permanent appliances, air vents, electrical, plumbing, etc.
- Start sketching your cabinets. Start in the 0", 0" corner and work outward.

The diagram illustrates two kitchen cabinet layouts. On the left, a wall cabinet is mounted above a base cabinet. The wall cabinet has a height of 30 inches. The total height from the floor to the top of the wall cabinet is 96 inches. On the right, a similar setup is shown, but with a soffit (a flat surface) above the wall cabinet. The wall cabinet height is still 30 inches, and the total height from the floor to the top of the wall cabinet is 96 inches. The soffit is labeled 'Soffit'.

Three diagrams illustrating cabinet configurations for different heights:

- 84" Configuration:** The top section has a height of 30" and the base section has a height of 84".
- 90" Configuration:** The top section has a height of 36" and the base section has a height of 90".
- 96" Configuration:** The top section has a height of 42" and the base section has a height of 96".

Diagram illustrating the dimensions and components of a corner base:

- Overall width: 36"
- Overall height: 36"
- Corner Base with Lazy Susan: 28-1/2" (width) x 24" (height)
- Adjacent Base (top right): 24" (width) x 24" (height)
- Adjacent Base (bottom left): 24" (width) x 16-1/2" (height)
- VOID: The central rectangular area.

Diagram illustrating the required filler for a 24 inch x 24 inch x 24 inch void. The void is shown as a rectangular box. The top of the void is labeled "VOID". The bottom of the void is labeled "Base". The side of the void is labeled "Base". The top of the void is labeled "3" Filler Required". The side of the void is labeled "6" Filler Required". The dimensions are 24" x 24" x 24".

