

18oz Christmas Theme Glass Use and Care Manual

1. Product Components

The package includes: 1 × 18oz glass cup, 1 × bamboo lid, 1 × glass straw, 1 × cleaning brush, 1 × straw topper.

2. Usage Instructions

- This glass is suitable for cold and iced beverages like juice, coffee, smoothie, etc. It withstands temperatures between -68°F to 340°F (170°C); avoid exceeding this range to prevent damage.
- When using the lid, gently place it on the glass mouth; do not press hard to prevent lid deformation.
- The straw can be directly inserted into the lid hole for drinking; avoid using excessive force to insert or pull out the straw to prevent glass straw breakage.

3. Cleaning & Maintenance

- After use, rinse the glass and straw with warm water in time. Use the attached cleaning brush to clean the inner wall of the straw and glass for thorough dirt removal.
- Bamboo lids should be wiped with a damp cloth; do not soak them in water for a long time to prevent mold or deformation.
- Do not use abrasive cleaners, steel wool, or hard brushes to clean the glass surface, as this may scratch the Christmas sprinkle cookie tree pattern and affect the appearance.
- The glass and straw are dishwasher safe (place in the top rack), but it is recommended to wash them by hand to better protect the pattern and extend product life.

4. Precautions

- The glass is fragile; avoid collision, falling, or heavy pressure. If there is a crack or breakage, stop using it immediately to prevent injury.
- Keep the product away from the reach of children to avoid accidental breakage and injury.
- Do not use the glass in microwave ovens, ovens, or freezers.

- Store the product in a dry and clean place when not in use; avoid prolonged exposure to direct sunlight to prevent fading of the Christmas sprinkle cookie tree pattern.