
IMPORTANT SAFEGUARDS

**When using electrical appliances, basic safety
Precautions should always be taken, including the Following:**

1. READ ALL INSTRUCTIONS.
2. Unplug the power cord from the power outlet before assembling, disassembling, cleaning or putting your hands near any moving parts of the appliance to avoid injury.
3. To protect against the risk of injury due to electric shock, do not immerse the motor base of the blender in water or any other liquid.
4. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they are supervised or have been given instruction concerning the use of the appliance by a person responsible for their safety.
5. Children should be forbidden to use the blender.
6. Do not use carbonated liquids in the blender container, or in any blending container. Using carbonated liquids in a blender container may result in injury.
7. Do not pour boiling water into the blender container.
8. Do not blend liquids for more than 7 minutes.
9. Don't contact the moving parts.
10. Do not operate the blender if the power cord or plug are damaged, or if it malfunctions or is damaged in any way. You need to return appliance to the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.

-
11. The use of attachments, including canning jars, is not recommended by the manufacturer and presents a risk of injury.
 12. Do not use it outdoors.
 13. Do not let cord hang over edge of table or counter, or touch the hot surfaces.
 14. Keep hands and utensils out of container when blending to prevent the possibility of severe personal injury and damage to the blender. A plastic scraper may be used, but it only can be used when the blender is not running.
 15. Blades are sharp. Handle carefully.
 16. Always operate blender with jar cover in place.
 17. Please check Cleaning and Maintenance instructions.
- Add: Not for water jet cleaning.
18. Always operate blender with removable silicone gasket in place.
 19. Do not fill the blender above the MAX FILL LINE.
 20. If the container overflows during blending, there is too much liquid/ingredients in the container. Stop blending, remove any liquid/ingredients above MAX FILL LINE, and resume blending. Do not operate if overflowing.
 21. Do not operate the blender in an appliance garage to prevent the risk of injury or fire. When storing in an appliance garage, always unplug the unit from the electrical outlet.
 22. The use of ear protection is recommended during extended operating periods.
 23. Ensure the jar coupler and motor coupler are aligned and locked before operating. If unable to lock, remove the container and shake the contents before trying again.
 24. Do not touch the coupling seal after blending as it may be hot.
 25. Replace silicone gasket if worn.

TO RESET THE UNIT

Your blender is equipped with a Resettable Thermal Protector to protect the motor. If the motor shuts down, unplug the blender, let the blender rest for approximately 15 minutes. Then, plug the blender again and resume blending. If your blender still doesn't work properly, following this procedure, stop using it and contact a certified Consumer Service Center.


SAVE THESE INSTRUCTIONS

FOR HOUSEHOLD USE ONLY

UNPACKING INSTRUCTIONS


1. Place the box containing blender on a flat, sturdy surface before unpacking.
2. Open box and remove instruction book and any printed materials from top of box.
3. Remove packing materials and all components. CAUTION: Sharp blade is in blender container.
4. Place all packing materials back into the gift box and save, in case they will be needed in future product shipments.

FEATURES AND COMPONENTS



-
1. Small lid and 130ml measuring cup.
 2. Tight-sealed blending jar lid.
 3. Blending Jar: 2 litre BPA free jug. Includes Imperial and Metric graduation.
 4. Removable silicone gasket.
 5. Motor base, which houses the high performance motor.
-

CONTROL PANEL



OPERATING INSTRUCTIONS:

1. Place the blender base on a clean, dry, flat, and sturdy surface.
2. Place the blending jar on the motor base.

3. Place all the ingredients in the jar and cover the jar with the lid. Secure the measuring cup to the lid by turning it counter-clockwise. You can add soft ingredients during the blend cycle by removing the measuring cup and dropping ingredients through the fill area but always close the lid with the measuring cup after adding any ingredient. Do not add ice or hard ingredients while the blender is running.
4. Plug the power cord into an electrical outlet. Do not put your hands in the jar when the blender is plugged in.
5. Make sure the dial is in the OFF position. Then, turn the dial to select the preferred manual mode or preset program.
6. Start blending.
-

PRESET FUNCTION

 “ ” :Ice and Cleaning	 “ ” : Milkshake
 “ ” :Hot Soup	 “ ”: Juice
 “ ”: Nuts	

BLENDER CLEANING AND MAINTENANCE

Always clean the blender after each use for hygiene purposes and to ensure its longevity.

Leaving food in the blender is a health risk as bacteria can grow. It can also cause the blending jar to stain. Bacteria and residual food acids can also damage the seals and shaft of the blades.

TO CLEAN THE BASE:

1. Switch off and unplug the blender from the power outlet.
2. Using a soft, damp cloth, wipe the surface of the blender's base. You can use a mild detergent to remove dried food if required. Never immerse the motor base in water or other liquids.
3. Use a dry soft cloth to thoroughly dry the blender.

TO CLEAN THE BLENDING JAR:

1. After each use, rinse the blending jar thoroughly with warm soapy water (not hot).
2. Place one or two drops of dish soap in the jar and fill it halfway with warm water.
3. Secure the lid and mount on the base.
4. Start the blender at LOW and slowly increase to level 5 speed.
5. Run on level 5 for 10-60 seconds (depending on what was blended; thick contents take longer to clean).
6. Pour the contents out and rinse thoroughly.
7. Turn the blending jar upside down and let air dry.

Remember: The blending jar, blade assembly and lid assembly are all dishwasher safe (place on the top shelf of the dishwasher only).

**FOR A DEEP CLEAN, PERFORM THE FOLLOWING STEPS
MONTHLY OR AS NEEDED:**

Place 2 cups of cool water and 2 cups of white vinegar into the blending jar and let them soak for between 12 and 24 hours. Pour the contents out and rinse thoroughly. Then follow the appropriate cleaning instructions above.