



FIBER OPTIC TREE ASSEMBLY INSTRUCTIONS

6515-48 (877615-H28320-01), 6515-24 (877615-H28320-02), 6515-36 (877615-H28320-03),
6516-36 (877615-H48771-03), 6516-48 (877615-H48771-02), 5598-35C (8776-H53380-03),
5597-24C (8776-H53370-04), 5596-24C (8776-H53360-04), 5599-40C (8776-H53890-01)

Before you start to set up your tree, please read this instruction sheet carefully.

1. Remove all parts from the box such as tree stand or tree pot, tree top, tree body sections.
2. Set up tree stand in cross shape or take out the pot .
3. Remove the packaging (foam, bubble wrap, cord, etc.) to arrange all wrapped tips into place.
4. Fiber optic tree with lights

Find the LED light source base at the side of your tree stand or tree pot.

First connect LED light source with its base;

secondly connect the other end with adapter;

thirdly connect the adapter with the light string's inserts,

finally connect the light string's plug into power supply.

If it is a fiber optic tree without lights, you only need to connect the adaptor directly with the power supply.

5. Shape the tree by arranging branches into the desired position. Finished look should be natural looking and full.
6. Your tree is ready to be decorated and enjoyed.
7. For indoor use .

WARNING -Risk of fire, personal injury and electrical shock.

1. Do not leave the tree unattended while it is power-on.
2. Replace any missing or broken bulbs before plugging in.
3. Do not place near gas or electric heaters, radiators, fireplaces, candles, outdoor heaters, barbecues or other similar sources of heat.
4. Place on a level, hard, flat surface: do not place where tree is likely to wobble due to uneven floors or thick carpeting.
5. After assembling the tree and adding decorations, make sure the tree is stable. If tree is not stable, shift the weight of the decorations, and use support wires to walls and/or window frames (make sure they are secure also).
6. Do not install near fountains, bathtubs, sinks, pools, hot tubs or other wet areas.
7. Do not use candles on this tree.
8. Do not overload power strips, or any other power receptacles. Make sure that the electrical rating of the tree and any other device connected to the same receptacle is below the maximum rating of the extension cord (if a tree is supplied with an extension cord.), power strip or other power receptacle.
9. This is an electrical product – not a toy! To avoid risk of fire, burns, personal injury and electrical shock it should not be played with or placed where small children and pets can reach it.


STORAGE:

- (1) Unplug light cord from the wall outlet and remove all ornaments and decorations.
- (2) Unplug each section.
- (3) Gently lift off the tree top and remove the bottom section from the tree stand. Carefully place the tree in its box and tape it shut. DO NOT STORE TREE IN A DAMP AREA OR IN AN AREA WHERE THE TEMPERATURE EXCEEDS 100⁰ F.

TROUBLE SHOOTING INSTRUCTIONS

If Lights Do Not Work:

1. Check whether the plug is properly plugged into the outlet.
2. Be sure there is power to the outlet.
3. Check whether all plugs within the tree are securely connected.
4. Check whether all bulbs are tightly inserted into lampholders and replace any missing or broken bulbs.
5. Check the light string fuse in the section plug that is out, but unplug tree first. If the fuse is blown (see if wire inside is intact or glass is blown). Replace the blown fuse following the diagram. There is a spare fuse included for easy replacement.



If a bulb does not work:

- a. First remove the bulb and make sure the wires are on either side of the bulb adaptor so that they will contact with the brass inside the lampholders and reinsert.
- b. If bulb still does not light, it is blown, remove the bulb and replace only with the supplied replacement bulbs following the diagram below.



FLAME RETARDANT

MADE IN CHINA