

INSTALLATION

This Hose and Reel is suitable for installation close to a water supply. The distance from the faucet to the Hose and Reel can be extended by adding an additional length of hose.

When installed to a wall or post, follow these steps:

1. Attach the spray nozzle to longer, retractable hose.
2. Install mounting bracket to the wall or post as in FIG. 1. The wall mounting may be attached to a stone or brick wall. If attaching to a wood surface, lag bolts (not included) are needed. There are many alternative positions in which the equipment may be placed. The important thing is to locate the hose where it is most convenient for the user. The wall mounting has 4 holes, one each taking an expansive bolt. Each bolt must be fitted with a flexible washer or cushioning piece.
3. Connect the reel to the mounting bracket with the metal tube (pin).
4. Attach the brass connection on the leader hose to the faucet or water tap.



FIG. 1

ADDITIONAL PRECAUTIONS WHEN USING THE HOSE AND REEL

The Hose and Reel comes with a high-quality, UV-protected, kink-resistant hose. After use, turn off the water supply, empty out the water remaining in the hose by opening the valve on the nozzle. Gently tug on the hose to begin retracting the hose onto the reel. In certain areas where the temperatures or water pressures are high, the sunlight may heat up the water and damage the hose, making the hose difficult to reel in. You are therefore advised always to reel in your hose after use. Do not leave the hose reel outdoors when temperatures are below 32 degrees. In such conditions, the hose may be less flexible and more difficult to reel in. The hose should never come in contact with chemicals or other substances such as acetone, mineral spirits, acids, etc. *Please note that the hose supplied with this hose reel should never be used for drinking water.*

