

TROUBLESHOOTING GUIDE

⚠ WARNING

Troubleshooting is to be performed only by qualified personnel.

Symptom	Possible Cause(s)	Corrective Action
Unit fails to operate	1. Power cord not plugged into proper outlet	1. Plug power cord into proper outlet
	2. Blown fuse or open circuit breaker	2. Replace fuse or reset circuit breaker
	3. No power	3. Contact power company
	4. There may be some obstructions in the fan.	4. Check for any obstruction. If you find an obstruction, turn the fan off. Unplug the fan and carefully remove the obstruction. Plug the fan in and turn it on again.