Installation Guide

VONN
CREATIVE INNOVATIONS

LED INFO & WARNINGS ⚠

- Please read and comprehend the entire manual before attempting to assemble, operate, or install the product.
- Make sure that you have all necessary parts by checking the parts list. If any part is missing or damaged, please contact **VONN Lighting Customer Service at 888-604-8666** for a replacement.
- All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn or broken.
- Inspect the LED fixture prior to installation to make sure that it has not been damaged during shipping.
- Please handle the LED light with care when unpacking. Do not apply pressure to the LED's, do not open any factory sealed compartments, and do not touch the LEDs with your hands.
- VONN highly recommends to use a qualified, licensed electrician to install the fixture.
- VONN recommends to install the fixture on its own independent circuit. Do not install the fixture on the same circuit with other appliances, or HVAC systems.
- Do not remove or replace VONN manufactured driver that is provided with the fixture.
- Shut "OFF" the electricity at main fuse box.
- Place the wall switch in the "OFF" position of the room you are installing the fixture.

VONN Lighting
Model: VMCF41200

C **ETL** US
LISTED

Intertek

EnabLED
Licensing Program for LED
Luminaires and Retrofit Bulbs

Member
Vonn LLC

ENAB**LED**

Parts List

A. Mounting Bracket
B. Plastic Anchors x 3
C. Anchor Screws x 3
D. Outlet Screws x 3
E. Wire Connectors x 3
F. Ground Screw x 1

Circuit Box

OFF

ON

⚠

OFF

## Tools You May Need

GOGGLES | TAPE MEASURE | RUBBER GLOVES | PHILLIPS SCREW DRIVER | DRILL | LADDER

Fixture Diagram

Ceiling

B Plastic Anchor

A Mounting
Bracket

C Anchor
Screw

E Wire
Connector

D Outlet
Screw

F Ground
Screw

Step 1. Install Mounting Bracket

Outlet Box

Ceiling

A Mounting Bracket

A Mounting Bracket

Remove mounting bracket (A) from fixture by pushing away from magnet and lifting up. Raise mounting bracket (A) to the ceiling. Mark location for the plastic anchors (B). Use drill to drill holes for plastic anchors (B). Insert plastic anchors (B) into hole.

Outlet Box

Ceiling

B Plastic Anchor

A Mounting Bracket

C Anchor Screw

D Outlet Screw

Attach mounting bracket (A) to outlet box with outlet screws (D). Screw anchor screws (C) into plastic anchors (B) to secure mounting bracket (A).

Step 3. Connect Wires

VONN
CREATIVE INNOVATIONS

Ceiling

Black
(Line Wire)

F Ground
Screw

E Wire
Connector

Bare Copper
(Ground Wire)

White
(Neutral Wire)

Supply Wires:

Connect Black (Line Wire) from fixture to Black (Hot Wire) from outlet box.

Connect White (Neutral Wire) from fixture to White (Neutral Wire) from outlet box.

Ground Wires:

Connect Bare Copper (Ground Wire) from fixture to Green or Bare Copper (Ground Wire) from outlet box.

Twist wires together clockwise and secure with wire connector (E).

Installer Tip: If ground wire is not available in outlet box, then secure Bare Copper (Ground Wire) from fixture to ground screw (F) on mounting bracket (A).

Step 4. Mount Fixture

Ceiling

A Mounting Bracket

Magnet

Attach fixture to mounting bracket (A) and push in the direction of the magnet until it connects.

Step 5. Turn Power ON

**Turn electricity "ON" at main fuse box.
Place the single pole switch in the "ON" position to test the fixture.**

Circuit Box

ON

ON

OFF

© VONN Lighting, 2018