

# Care & Maintenance

**Do not use any harsh abrasives, polishes or chemicals! Do not wash any glass or parts in the dishwasher!**

## **FINISH CARE & CLEANING:**

Initial care for finishes requires only periodic cleaning with a soft cloth, dampened with water. A mild non-abrasive soap may be used along with a soft cloth and water if the fixture is very dirty. Particular care should be taken to avoid abrasive materials and strong cleaning agents as they will quickly destroy the protective coatings and subject the finish to rapid oxidation and/or discoloration.

## **FABRIC SHADES**

Use a fine brush or a lint remover on your shade to remove the accumulated dirt and dust. If necessary, you may use a white cloth dampened with a mild solution of soapy water to wash the shade gently and evenly. Rinse thoroughly with a white cloth dipped in clean water. The shade should be allowed to dry quickly, preferably in the sun or by using a hair dryer. You may also use a home dry cleaning product.

## **GLASS SHADES**

Use a clean, soft cloth to wipe your shade. If necessary, you may use a white cloth dampened with a mild solution of soapy water to gently wash the shade. Rinse thoroughly with a white cloth dipped in clean water. A mild glass cleaner may also be used.

## **OUTDOOR FIXTURES**

Finishes on Outdoor Lanterns must be properly maintained and treated. Use a clean, soft cloth to wipe the fixture. To help preserve the finish, a high quality car wax may be applied to the metal twice a year. A glass cleaner may be used to clean the glass only; do not use the glass cleaner on any part of the fixture.