

- Remove the protective cover and insert the Tool Connect™ Chip into the empty pocket **23**.
- Ensure that the Tool Connect™ Chip is flush with the housing. Secure it with the retaining screws and tighten the screws.
- Refer to **Tool Connect™ Chip Instruction Sheet** for further instructions.

Repairs

The charger and batteries are not serviceable. There are no serviceable parts inside the charger or battery pack.

▲ WARNING: To assure product **SAFETY** and **RELIABILITY**, repairs, maintenance and adjustment (including brush inspection and replacement, when applicable) should be performed by a factory service center or an authorized service center. Always use identical replacement parts.

Register Online

Thank you for your purchase. Register your product now for:

- WARRANTY SERVICE:** Registering your product will help you obtain more efficient warranty service in case there is a problem with your product.
 - CONFIRMATION OF OWNERSHIP:** In case of an insurance loss, such as fire, flood or theft, your registration of ownership will serve as your proof of purchase.
 - FOR YOUR SAFETY:** Registering your product will allow us to contact you in the unlikely event a safety notification is required under the Federal Consumer Safety Act.
- Register online at www.dewalt.com/account-login.

Three-Year Limited Warranty

For warranty terms, go to www.dewalt.com/support/warranty.





To request a written copy of the warranty terms, contact: Customer Service at DEWALT Industrial Tool Co., 701 East Joppa Road, Towson, MD 21286 or call **1-800-4-DEWALT (1-800-433-9258)**.

LATIN AMERICA: This warranty does not apply to products sold in Latin America. For products sold in Latin America, see country-specific warranty information contained in the packaging, call the local company or see website for warranty information.

FREE WARNING LABEL REPLACEMENT: If your warning labels become illegible or are missing, call **1-800-4-DEWALT (1-800-433-9258)** for a free replacement.

ACCESSORIES CHART

Approved wheels for use with DCG411VS, DCG410VS	
Type 1 / T1 / 41 / T41	
Type 27 / T27	
Type 28 / T28	
Type 29 / T29	
Non-approved wheels for DCG411VS, DCG410VS	
Type 11 / T11	 Do Not Use

5" (125 mm) Grinding Wheels	
Type 27 guard Type B guard	
Backing flange	
Type 27 Depressed center wheel	
Locking flange	
5" (125 mm) Grinding Wheels	
Type 27 guard Type B guard	
Type 27 hubbed wheel	
5" (125 mm) Sanding Flap Discs	
Type 27 guard Type B guard	
Backing flange	
Non-hubbed sanding flap disc	
Locking flange	
5" (125 mm) Sanding Flap Discs	
Type 27 guard Type B guard	
Hubbed sanding flap disc	
5" (125 mm) Cutting Wheels	
Type 1/41 guard** Type A guard**	
Backing flange	
Type 27/42 depressed center wheel, cutting only	
Locking flange	
5" (125 mm) Cutting Wheels	
Type 1/41 guard** Type A guard**	
Backing flange	
Type 1/41 abrasive cutting wheel	
Locking flange	