

Installation Instructions

Use teflon tape on threaded PVC male adapter and tighten into valve body using a wrench. The anti-siphon valve should be installed 6" to 12" above the highest outlet or sprinkler. Check local codes for backflow prevention requirements. There must not be any valve downstream of the anti-siphon valve. [See Uniform Plumbing Code, Sec. 1003 (2) (7)]. Anti-Siphon valves must not be operated continuously for more than twelve (12) hours. (See American Society of Sanitary Engineering Standard 1001, Sec. 1.5.2.4)

Installing the Valve

1. Flush line thoroughly before installing valve.
2. Use teflon tape on threaded PVC male adapter and tighten into valve body using a wrench. (Note: Do not use pipe dope).
3. Manually turn the sprinklers on and off by turning the handle.

Automatic Conversion for 3/4" Manual Anti-Siphon Valve

Convert your 3/4" Manual Anti-Siphon Valve into an automatic valve with Lawn Genie Valve Adapter (Model #L2034). Where local water pressure exceeds 80 PSI, a pressure regulator should be used. [See Uniform Plumbing Code, Sec. 1007 (b)]

Automatic Conversion for 1" Manual Anti-Siphon Valve

Convert your 1" Manual Anti-Siphon Valve into an automatic valve with Lawn Genie Valve Adapter (Model #L2010). Where local water pressure exceeds 80 PSI, a pressure regulator should be used. [See Uniform Plumbing code, Sec. 1007 (b)]



The Lawn Genie Promise

Limited One-Year Warranty

Lawn Genie and its affiliate, Lawn Genie Warranty Company, pursuant to an agreement between them, jointly warrants, to the owner, against defects in material and workmanship for a period of one year from the date of purchase.

We are not liable for failure of products not manufactured by Lawn Genie even though such products may be sold or used in conjunction with Lawn Genie products.

During such warranty period, we will repair or replace, at our option, any part found to be defective.

Return the defective parts to the place of purchase.

Our liability is limited solely to the replacement or repair of defective parts. There are no other express warranties.

This warranty does not apply where equipment is used, or installation is performed, in any manner contrary to Lawn Genie's specifications and instructions, nor where equipment is altered or modified.

NEITHER LAWN GENIE NOR LAWN GENIE WARRANTY COMPANY IS LIABLE FOR INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH THE USE OF

EQUIPMENT, INCLUDING BUT NOT LIMITED TO: VEGETATION LOSS, THE COST OF SUBSTITUTE EQUIPMENT OR SERVICES REQUIRED DURING PERIODS OF MALFUNCTION OR RESULTING NON-USE, PROPERTY DAMAGE OR PERSONAL INJURY RESULTING FROM INSTALLER'S NEGLIGENCE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

ALL IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR USE, ARE LIMITED TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states do not allow limitations of how long an implied warranty lasts, so the above limitation may not apply to you.

This warranty gives you specific legal rights and you may have other rights which vary from state to state.

For technical support:
P.O. Box 489, Riverside, CA 92502
1-800-231-5117

© 2000 Lawn Genie
All Rights Reserved
Part No. 102-1174