



EASY ASSEMBLY AND OPERATION INSTRUCTIONS

22SV23279 Cauldron Witch Duo

READ AND SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

IF ANY PART IS MISSING OR BROKEN, DO NOT ATTEMPT TO ASSEMBLE THE PRODUCT AND CONTACT SVI CUSTOMER SERVICE FROM 8:30AM TO 5:30PM PST AT 1-855-428-3921, EMAIL CUSTOMERSERVICE@SVIUS.COM, OR CALL HOME ACCENTS HOLIDAY CUSTOMER SERVICE FROM MON-FRI 8:00AM TO 7:00PM AND SAT 9:00 AM TO 6:00 PM EST AT 1-855-HDHOLIDAY (1-855-434-6543).

IMPORTANT TIPS:



- Ensure that the item's adapter is plugged in at the Function Control Box and in the wall.
- Ensure that the switch on the function control box is on the desired setting.
- If not functioning properly (ex: Mouth doesn't move, eyes don't light up, body doesn't move), ensure that cables are connected to their corresponding cable as shown in the instruction sheet.
- Be sure nothing is blocking movement or caught in moving parts.
- Ensure that the floor or surface that the item sits on is flat and level.
- Ensure that the volume is not all the way down.
- Be sure nothing is blocking the sensor.
- If the item still does not work, contact SVI Customer Service from 8:30am to 5:30pm PST at 1-855-428-3921, email customerservice@svius.com, or call Home Accents Holiday Customer Service from Mon-Fri 8:00am to 7:00pm and Sat 9:00 am To 6:00 pm EST at 1-855-HDHOLIDAY (1-855-434-6543).

PARTS LIST

- A. Base x 1
  - B. Left Support Pole x 1
  - C. Right Support Pole x 1
  - D. Left Costume x 1
  - E. Left Torso Frame x 1
  - F. Left Hip Hoop x 1
  - G. Shoulder Frames x 2
  - H. Left Head x 1
  - I. Left Witch Left Arm x 1
  - J. Left Witch Right Arm x 1
  - K. Right Hip Hoop x 1
  - L. Right Witch Skirt x 1
  - M. Right Torso Frame x 1
  - N. Right Shirt x 1
  - O. Right Head x 1
  - P. Right Witch Left Hand x 1
  - Q. Right Witch Right Hand x 1
  - R. Embers x 1
  - S. Cauldron Front x 1
  - T. Cauldron Rear x 1
  - U. Stirring Motor x 1
  - V. Cauldron Lights x 1
  - W. Bone Stirrer x 1
  - X. Stirrer Support x 1
  - Y. Bone Belt x 1
  - Z. Apron x 1
  - Z1. Left Cape x 1
  - Z2. Rt. Shawl x 1
  - Z3. Left Hat x 1
  - Z4. Right Hat x 1
  - Z5. Adapter \* x 1
- \* Power Adapter Spec  
Input: 100 - 240VAC 50/60Hz  
Output: 5.9V 3A




NOTE: Throughout the instructions, Right and Left are from the character's point of view.





NOTE: The (D) Left Costume's opening should be facing the back.








NOTE: Thread the cables from the (E) Left Torso Frame through the (D) Left Costume.















**IR SENSOR**  
Be sure nothing is blocking the sensor.


**YOUR CAULDRON WITCH DUO IS NOW FULLY ASSEMBLED. PLUG IN AND TURN ON TO LET THE FUN BEGIN!**

**OPERATION INSTRUCTIONS:**

1. Plug the power adapter into a standard power outlet and adjust the settings on the Function Control Box, located on the Right Torso Frame, as desired.

2. Settings:

Sensor / Détecteur	This switch mode will activate lights, sound, and animation when the Infra-red (IR) sensor is activated and will operate for 1 audio-cycle with each activation. The Infra-red (IR) sensor has a range of up to 2 m/6.5 ft. and will activate when someone comes within an 80-degree angle from left-to-right, as well as from above and below.
○	This switch mode allows the item to be activated only if triggered by using a Step Here Try Me Activation Pad (Not Included). The item will operate for one audio cycle with each Try Me activation. Otherwise, the item will stay off.
I	This switch mode will continuously operate the lights, sound, and animation of the item.
⌚	Raise or lower the volume using the volume control turn dial, turn all the way down to turn the volume off .



**WARNING**

This item is not a toy and should be used for decoration only. This item contains small parts that can be a choking hazard. Keep all plastic and wire parts away from children.

1. Please use the adapter supplied by manufacturer.

2. Please assemble item according to instructions. Connect all wires according to matching color.

3. Children should be supervised by adults. Item should not be grabbed, as it becomes a tipping hazard. Keep flammables away from the adapter, as it heats up during operation.

Please view all instructions carefully before assembling. Save this instruction sheet for future reference.

**CARE AND STORAGE INSTRUCTIONS**

For best performance operate your item indoors. When not in use, store this product in its original packing. Keep away from heat and moisture.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**CAUTION:** Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna, Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

CAN ICES-003(B)/NMB-003(B)