### **USE AND CARE GUIDE**

### **CAYMAN BISTRO TABLE**



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

**HAMPTONBAY.COM** 

#### THANK YOU

### **Table of Contents**

Table of Contents	Pre-Assembly3
Safety Information	Hardware Included
What is covered	Package Contents
What is not covered	Assembly
Warranty	Cleaning and Maintenance
**ananty	Service Parts7

### **Important Safety Instructions**

#### READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- 2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.

### **SET UP YOUR FURNITURE PROPERLY**

- 1. Ensure that all parts are assembled properly and fully tightened as per the instructions.
- 2. When placing in the desired location, ensure that all legs are resting on the same surface.

#### **EXAMINE YOUR FURNITURE**

Examine occasionally to ensure that there are no loose parts. If loose parts are found, they must be re-tightened fully before additional use.

### **OBSERVE WEIGHT LIMITS**

The weight limits for the following products are listed below	The	weiaht	limits	for the	following	products	are listed	below:
---	-----	--------	--------	---------	-----------	----------	------------	--------

□ Chair: 300 lbs	Sofa: 700 lbs Sof
☐ Swivel Chair: 300 lbs	☐ Rocking Chair: 300 lbs
Loveseat: 500 lbs	☐ Chaise Lounge: 300 lbs
Ottoman: 150 lbs	☐ Dining Table: 100 lbs
☐ Table: 50 lbs	☐ Dining Chair: 200 lbs



CAUTION:

If you overload your furniture, injuries can occur.

### THREE YEAR FRAME, WEAVE AND FABRIC LIMITED WARRANTY

### WHAT IS COVERED

We warrant the frame, weave and fabric to be free of manufacturing defects to the original purchaser for three years. For glass table top we warrant 30 days from the date of purchase.

#### WHAT IS NOT COVERED

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty.


We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production. Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Hamptonbay.com.

### **Pre-Assembly**

#### PLANNING ASSEMBLY

To prevent damage, place all parts on a soft surface during assembly. Remove all protective caps before beginning assembly.

### HARDWARE INCLUDED





Part	Description		Quantity
AA	Bolt	<b>♦ 8x25 mm</b>	2
BB	Bolt	<b>♦ 8x20 mm</b>	4
CC	Washer	ф <b>8 mm</b>	6
DD	Cap for bolt	ф <b>8 mm</b>	6
EE	Hex wrench	5 mm	1


3

### **PACKAGE CONTENTS**










Part	Description	Quantity
Α	Table top	1
В	Large base	1
C	Small base	1
D	Grey painted glass	1


## Attaching the bases

- □ Place the large base (B) face down on a soft surface.
- Attach the small base (C) to the large base (B) by aligning holes on the small base (C) with the holes on the large base(B). The bases must be attached as this image shown. Insert bolts (AA) with washers (CC) and hand tighten.
  Do not tighten completely.



### **2** Attaching the bases to the top


- Place the top (A) face down on a soft surface.
- Attach the large base (B) and small base (C) to the top (A) by aligning holes on the large base (B) and small base (C) with the holes on the top (A). Secure alternating sides on legs when lining up holes. Insert bolts (BB) and washers (CC).



# 3 Adding the caps


- Check and make adjustments as needed.
- Fully tighten all the bolts (AA) and bolts (BB) with the Hex wrench (EE) and cover with the bolt caps (DD).

□ Adjust leg levelers as required.



# 4. Completing the assembly

- Place the table right side up.
- Put the grey painted glass (D) on the table top. Make sure the glass top is surrouned by the frame. Attention: The grey side of the glass is the top.
- □ This table is now ready for your enjoyment.



HAMPTONBAY.COM

# **Cleaning and Maintenance**

Ш	Before using, wipe with a clean, dry cloth. Do not use bleach or solvents. When not in use, store turniture in a cool, dry place.
	Do not use bleach or solvents on fabrics. When cleaning the table top make sure to use a soft, clean cloth that does not bleed color
	as well.
	Wash the frame with a mild solution of soap and water, rinse with clean water, and dry thoroughly.
	Cushions may also be cleaned by hand with a mild solution of soap and water. Rinse the cushion cover thoroughly and allow to drip dry. The
	back cushion and pillow should be spot cleaned with a soft cloth. Do not machine wash or tumble dry, as cushions may shrink. Do not use
	bleach or solvents on fabrics. Never use cleaners that contain acid or abrasive materials.
	Use and operation: To improve the lifespan of this furniture, cover when not in use and store in a dry place in the off season.

6

### **Service Parts**

Part	Description	Quantity
Α	Table top	1
В	Large base	1
С	Small base	1
D	Grey painted glass	1

7

# HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

**HAMPTONBAY.COM** 

Retain this manual for future use.