

PERCOLATOR INSTRUCTIONS



Usage instructions:

Add water to percolator, in the amount of how much coffee is desired (suggested minimum is 4 cups). Place basket into pot. (Depending on the coarseness of coffee grounds a filter may be used inside the basket.) Spoon coffee into basket. Suggested ratio is 1 tablespoon per cup of water, but can be varied due to desired strength. Close basket and lid and place coffee pot on heat source for brewing. When water begins to bubble, or percolate, lower the flame or heat source. Allow coffee to percolate for 5 to 15 minutes depending on strength desired. Shut off heat or remove pot from heat source.

Care instructions:

Hand wash with warm soapy water. Do not use steel wool or harsh abrasives.

STANDARD SALES, INC • 2801 EAST 12TH ST. • LOS ANGELES, CA 90023 • TOLL FREE 1-800-421-6131

PERCOLATOR INSTRUCTIONS



Usage instructions:

Add water to percolator, in the amount of how much coffee is desired (suggested minimum is 4 cups). Place basket into pot. (Depending on the coarseness of coffee grounds a filter may be used inside the basket.) Spoon coffee into basket. Suggested ratio is 1 tablespoon per cup of water, but can be varied due to desired strength. Close basket and lid and place coffee pot on heat source for brewing. When water begins to bubble, or percolate, lower the flame or heat source. Allow coffee to percolate for 5 to 15 minutes depending on strength desired. Shut off heat or remove pot from heat source.

Care instructions:

Hand wash with warm soapy water. Do not use steel wool or harsh abrasives.

STANDARD SALES, INC • 2801 EAST 12TH ST. • LOS ANGELES, CA 90023 • TOLL FREE 1-800-421-6131