

USE & CARE MANUAL

COLORSHOT[®] PREMIUM *Spray Paint*

USE ON indoor & outdoor projects, including wood, metal, most plastics, and crafts. Does not work on PP plastic. Test first in a hidden area.

PAINTING CONDITIONS Use outdoors or in a well-ventilated area. Avoid spraying in windy or dusty conditions. Use when temperature is between 50°F (10°C) and 90° F (32°C) & humidity does not exceed 70% to ensure proper drying. Do not apply to surfaces that, when heated, exceed 200°F (93°C).

PREPARATION Cover surrounding areas to protect from overspray. You'll regret it if you don't.

- Remove loose paint, rust, dirt, and grease from surface to be painted.
- Lightly sand shiny surfaces.
- Clean, rinse, and let dry completely.

WARNING! If you scrape, sand, or remove old paint, you may release lead dust. **LEAD IS TOXIC.** Contact the National Lead Information Hotline at 1-800-424-LEAD, or log on to www.epa.gov/lead.

PRIMING Use **COLORSHOT[®] Primer** for maximum adhesion & color vibrancy.

PAINTING Shake can vigorously for 1 minute after mixing ball begins to rattle. Seriously, one minute. This paint is highly pigmented and performs best when fully mixed. Shake often during use. Hold can upright 6"-10" from surface and spray in smooth, even strokes. Apply one light coat at a time, waiting a few minutes between coats.

DRY & RECOAT Recoat within 1 hour or after 24 hours. Dries to the touch in 10 minutes. Fully cured in 24 hours.

CLOGGING If valve clogs, pull off spray top and rinse with a solvent such as mineral spirits. Do not stick a pin or other object into opening.

CLEAN-UP Turn can upside down after use and spray for 5 seconds or until no spray comes out to clear valve and prevent clogging. Wipe off tip before storing.