

## **ASSEMBLY INSTRUCTION**

# VINING DOUBLE CART WITH OPEN STORAGE AND STONE TOP - STONE GRAY



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service.

8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-986-3460

#### HOMEDEPOT.COM/HOMEDECORATORS

#### THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this Stone Top Kitchen Cart.

We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

### Table of Contents

Table of Contents	2
Safety Information	
Warranty	
What is Covered	
What is Not Covered	2
Pre-assembly	3
Planning assembly	3
Tools required	3
Hardware Included	3

Pre -assembly (continued)	
Package Contents	
Assembly –	
Maintenance	
Care and Cleaning	7

### **Safety Information**



### **Danger**

- Keep small parts away from children and pets during assembly.
- Read and follow instructions carefully.



### Warning

- Read these instructions carefully and keep in a safe place.
- TO GUARANTEE THE SAFE USE OF THIS PRODUCT. FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL.
- Adult assembly required.
- Small parts may present choking hazard prior to assembly.
- Do not stand, step or climb on unit.



## **A** CAUTION

- Do not use power tools to assemble your furniture. Power tools may strip or damage parts/product.
- Do not overtighten connectors (screws, bolts, etc.). Overtightening can lead to product damage.
- Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact THE HOME DEPOT to obtain any missing parts.
- DO NOT USE SUBSTITUTE PARTS.
- This product should only be used on a flat, level surface.
- Assembly requires two people; assembly alone may cause injury.

### Warranty

#### 3 YEAR WARRANTY

#### WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for three years.

#### WHAT IS NOT COVERED

This warranty does not cover commercial use, acts of nature, and abusive use.

### **Pre-assembly**


#### **PLANNING ASSEMBLY**

Two people are required for the assembly of this product and Keep children and pets away from the assembly area. Make sure that area is large enough to unpack, sort, and assemble the unit.




**NOTE:** Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.

#### **TOOLS REQUIRED**




#### HARDWARE INCLUDED



Part	Hardware description	Quantity
AA	M6x25mm,	2
BB	Washer Ø16x8mm	2
CC	Allen key Ø4mm	1

## **Pre-assembly (continued)**

#### **PACKAGE CONTENTS**




Part	Part Name	Quantity
Α	CABINET	1
В	TOWEL BAR	1
С	STONE TOP	1

### **Assembly**

### Take out the drawer

Use the mechanism shown for metal runners,
 Push the locks as per the direction shown to
 pull the drawer out from the box.




## 2 Assemble the towel bar

 Assemble the Towel bar (B) with Allen bolt (AA) and washer (BB) with the help of Allen key (CC).



## 3 Insert the drawer

Insert the drawer in the drawer box.



## 4 Place the stone top

Place the stone top (C) gently on the base unit (A).



## Assembly



### **Maintenance**

	Keep the prod	luct away from	direct heat &	& sunlight.
--	---------------	----------------	---------------	-------------

- □ Prolonged exposure to heat sources may cause scorching, or even cause color to fade.
- Regular vacuuming and light brushing helps to remove dirt and prevent soil buildup, which increases the appearance of wear.
- □ Hardware may loosen over time. Periodically check to make sure all connections are tight. Re-tighten if necessary.

## **Care and Cleaning**

- □ Vacuum your product regularly. Small dust particles are very abrasive and can wear furniture prematurely.
- □ Never use harsh chemicals or solvents on your product as this may damage the surface.
- Marks and stains from pens, crayons and ink markers are difficult to remove. In the event that your product becomes permanently stained, we recommend that you consult a professional.



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service. 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-986-3460

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.