



Stainless Steel Commercial Restaurant Sinks

ASSEMBLY INSTRUCTION MANUAL

This manual covers all Koolmore one compartment, two compartment and three compartment sinks.

One Compartment Sink



Two Compartment Sink



Three Compartment Sink





Contact us

For assembly assistance, missing or damaged parts, please contact customer service. We're here to help, customer satisfaction is our number one priority.

Email: support@koolmore.com

Phone: 718-576-6342

Thank you for your purchase!

Table of Contents

1. General Information	Page 3
2. Parts List	Page 4
3. Cleaning and Maintenance	Page 5
4. Assembly Instructions	Page 6
5. Warranty Information	Page 10



1. General Information

This instruction manual covers the assembly procedures for all Koolmore one compartment, two compartment and three compartment sinks. The assembly instructions are identical for all three models of sink.

NOTE: This manual does not include instructions for the plumbing of the faucets or drains. For those installations, please contact a qualified professional.

Adjustable Bullet Feet

One-and-a-half-inch plastic bullet feet allow you to level the sink for the best possible stability, even on uneven surfaces. The hard-wearing plastic protects your floors from scratches.

High Backsplash And Raised Edges

The 10" backsplash with pre-punched holes for faucet mounting (not included) will keep walls dry and clean while the raised edges prevent splashes and overflow. The bowl has rounded corners to facilitate cleaning and maintenance.

NSF Certified

All Koolmore sinks are NSF certified, which means that they comply with strict standards for public safety and health, and are certified for use in commercial kitchens.



2. Parts List



Item	Quantity
A. Sink Unit	1
B. Sink Legs	4
C. Hex Key	1
D. Set Screw	9 (1 spare)
E. Sink Strainer	1
F. Basket Drain	1





Figure 1 - Sink Components

3. Cleaning and Maintenance

Koolmore sink units are manufactured from high-quality, durable stainless steel. This material is rust and corrosion resistant.

- To clean the sink unit, use mild detergent and non-abrasive cleaning products. Pure white vinegar is also highly effective for cleaning stainless steel. Do not use products containing bleach.
- Do not use steel wool, brushes or scourers when cleaning the sink.

WARNING: DO NOT USE METALLIC OR SHARP INSTRUMENTS TO REMOVE DIRT, AS THESE MAY SCRATCH THE SURFACE AND DAMAGE THE SURFACE.

- Make sure to rinse sink with clean hot water after each use, and after cleaning
- Remove food residue and any residue of cleaning products or grease to avoid staining and discoloration.
- Leaving cloths, sponges and cooking utensils in or on the sink for extended periods may also cause discoloration.
- Regularly drying your sink unit will help to avoid water spots on the surface.

WARNING: NEVER USE THE STAINLESS STEEL DRAINING BOARD AS A CUTTING SURFACE. KNIVES OR OTHER SHARP UTENSILS WILL DAMAGE THE SURFACE OF YOUR SINK UNIT.



4. Assembly Instructions

To assemble your sink unit, there are eight simple steps to follow.

Step 1: Unpack the contents of the box, verifying that all the parts are present (see Section 2: Parts List).

Step 2: Place the sink unit on its side, with the backsplash panel facing down, as shown in Figure 2 below.

NOTE: Take care to avoid placing the sink on a surface that will scratch the sink unit.

WARNING: THE SINK UNIT MAY BE HEAVY, TAKE PRECAUTIONS TO AVOID INJURY WHEN MOVING AND LIFTING THE SINK ASSEMBLY.



Figure 2 - Underside of Sink Unit



Step 3: Insert the four legs into the corresponding gussets on the underside of the sink. Then insert the set screws into the set screw holes on the legs. There are two set screws per leg.



Figure 3 - Inserting the Legs

Step 4: Tighten the set screws using the hex key provided.

NOTE: Do not use excessive force as this will damage the sink leg.



Figure 4 - Tightening the Set Screws

Step 5: Carefully turn the sink over onto its legs, placing it down on all four legs simultaneously to avoid stress on any individual leg.

WARNING: TAKE CARE WHEN TURNING THE SINK UNIT OVER AS IT MAY BE HEAVY. WE RECOMMEND THAT TWO PEOPLE LIFT THE UNIT TOGETHER TO AVOID INJURY.

Step 6: Position the unit in the desired location, and use the adjustable bullet legs to ensure that the unit is level. To adjust the bullet feet, simply twist them until the desired extension is achieved.



Figure 5 - Adjusting the Bullet Feet

Step 7: The sink strainer consists of six parts, as shown in Figure 6, on the next page. These are:

- A. Strainer
- B. Rubber Washer
- C. Cardboard Washer
- D. Locknut
- E. Tailpiece Nut
- F. Tailpiece Washer






Figure 6 - Strainer Parts Breakdown

NOTE: To install the sink strainer correctly, you will need plumbers putty and a locknut wrench or suitable alternative. These items are not included with the sink assemble.

Ensure that the drain hole and surrounding areas are clean and dry. Apply a ring of plumber's putty around the drainhole on the inside of the sink.

NOTE: Parts E (tailpiece) and F (tailpiece nut) do not have to be removed in order to install the sink strainer assembly. Leave these parts attached.

Insert the strainer (A) into the hole. Then, from the bottom, attach parts B, C and D in the order shown in Figure 6 above. First the rubber washer, then the cardboard washer, and finally the the lock nut. Hand tighten the locknut using a suitable wrench.

Step 8: The sink unit is now assembled and ready to be plumbed in. The unit can now be affixed to a wall using suitable hardware, if necessary. If placing against a wall, remember to use appropriate silicone sealant or an alternative to contain any water spillage.

5. Warranty Information

Product Registration

Please register your product online at www.koolmore.com. Registering your products will expedite any warranty claims and also allow us to communicate any critical product-related notifications and updates.

90 Day Warranty

Unless otherwise stated, Koolmore sinks are backed by a 90-day warranty. This warranty guarantees that new, qualified products will be free from defects in material and workmanship under normal use during the specified warranty period. This warranty is void on products sold or shipped outside of the United States. This



warranty is only valid to the original purchaser of Koolmore products. If a qualified product is found to be defective during this period, Koolmore will repair the defective product, replace any defective parts, or replace the defective product.

What This Warranty Does Not Cover

Koolmore will not warrant coverage for product failure or damages that arise under the following conditions:

- Failure to install and/or use the unit within proper operating conditions.
- Installation in non-commercial or residential applications.
- Products sold or used outside of the United States.
- Any damage that occurs as a result of negligence or improper handling.

Additionally, no claims can be made against this warranty for spoilage of products, loss of sales or profits, or any other consequential damages. If defects are the result of freight or handling damage your first recourse must be to notify the delivering freight carrier. Any damage should be noted on the delivery receipt at the time of delivery. Refer these claims to the freight carrier for correction and compensation (this applies regardless of who was responsible for paying the freight charges or selecting the carrier).