

# TV Stand Care & Maintenance Guide

- **General Cleaning**

Use a soft, dry cloth to regularly dust the TV stand and remove dirt.

For deeper cleaning, use a slightly damp cloth with mild soap and water.

Avoid soaking the surface.

Immediately wipe off any spills to prevent staining or damage.

Avoid abrasive cleaners, solvents, or harsh chemicals which can damage finishes.

- **Surface Protection**

Use coasters, placemats, or felt pads under decorative items, electronics, or beverages to prevent scratches and heat damage.

Avoid placing hot items directly on the surface.

Keep sharp or rough objects away to minimize scratches.

- **Material-Specific Care**

Wood & MDF surfaces:

Avoid excessive moisture or water exposure to prevent warping or swelling.

Use furniture polish or wax occasionally to maintain luster, but ensure compatibility with the finish.

Metal components (legs, handles):

Wipe with a dry or slightly damp cloth to remove dust and fingerprints.

Dry immediately to prevent rust or corrosion.

Glass panels:

Clean with glass cleaner or a mixture of vinegar and water.

Use a soft lint-free cloth to avoid scratching.

- **Avoid Direct Sunlight & Heat**

Place the TV stand away from direct sunlight to prevent discoloration or fading.

Keep it away from heat sources such as radiators or vents to avoid material damage.

- **Weight & Usage Guidelines**

Do not exceed the maximum recommended weight capacity for the top surface, drawers, and shelves.

Distribute weight evenly to maintain stability and avoid structural damage.

Open and close drawers or doors gently to prolong hardware life.

- **Assembly & Structural Integrity**

Periodically check and tighten any screws, bolts, or fittings to ensure stability.  
If the TV stand has adjustable legs, ensure they are properly set to maintain balance.

- **Cable Management**

Use the designated cable holes or organizers to keep cords neat and reduce clutter.  
Avoid excessive bending or stretching of cables to prevent damage.

- **Long-term Storage**

If storing the TV stand for an extended period, keep it in a dry, climate-controlled environment.  
Cover with a breathable cloth to protect from dust while avoiding moisture buildup.