

USER MANUAL FOR MODEL# FD-4397-ZZU

Thank you for purchasing our product. For questions or assistance on assembly, parts or installation, please contact customer support:

Email: service@jojospring.com

Website: www.jojospring.com


Please include the product number, order number if any, and your phone number in the email. If there are broken or missing parts, please include the part numbers and quantities, and your address. You will be answered within 24 hours. For hard to explain problems, please send us a few pictures showing the problems if you can. We involve the factory technicians directly in the support, so you can be assured you will deal with the experts.

CAUTION

1. Rated 110-130V/60Hz, bulb 40W-60W maximum.
2. Care should be taken to avoid damage to the surface of lighting and wire. Wearing gloves are recommended when installing.
3. Keep lighting away from acid, alkali and other corrosive chemical or gas. Clean the lighting with clean soft cloth only.
4. Installation must be carried out by qualified electrician only.
5. Disconnect the power before installing, cleaning and replacing lighting.
6. Never cover the lighting when power is connected.


MISE EN GARDE

1. évalué 110 ~ 130V / 60Hz, ampoule 40W-60W maximum.
2. Des précautions doivent être prises pour éviter d'endommager la surface de l'éclairage et du fil. Le port de gants est recommandé lors de l'installation.
3. Gardez l'éclairage éloigné de l'acide, des alcalis et d'autres produits chimiques ou gaz corrosifs, nettoyez l'éclairage uniquement avec un chiffon doux et propre.
4. L'installation doit être effectuée uniquement par un électricien qualifié.
5. Débranchez l'alimentation avant d'installer, de nettoyer et de remplacer l'éclairage.
6. Ne couvrez jamais l'éclairage lorsque l'alimentation est connectée.




The wiring connection of luminaire and outlet box

There are two main wires. One is in black and the other is in white. Be sure to connect the black wire (positive electrode) to the outlet box wire (positive electrode), the white wire (negative electrode) to the outlet box wire (negative electrode) and the copper fixture ground wire to the supply ground wire with wire connectors.



Requires E26 40W-60W bulbs (not included)



INSTRUCTION

8/28/2021


2A. Lock the mounting bracket on the junction box of the ceiling by using 4 pcs of 5/32 screws in the accessories bag.

2B. Connect the wires. The black wire is the positive (+) wire. The white wire is the negative (-) wire. The bare wire is the ground wire.

2C. Cover the ceiling canopy and attach the screws to the canopy.


1A. Includes two 20.5 inches rods. Attach the rod (part #3) to the ceiling plate (part #2) and the fixture (part #4).

1B. Includes two spare chains, to adjust the fixture height when needed. Each chain length is 39.4 inches. Attach the chain (part #5) to the ceiling plate (part #2) and the fixture (part #4). The maximum height from the ceiling to the bottom of the light socket is 56.3 inches. The minimum height is 27.6 inches.



3. Install 8 E26 bulbs (Not included).

Please note: The parts in this table are completely unassembled, for illustrative purpose. In the actual product that you receive, some parts are assembled and attached together.



Part Number	Picture	Quantity
1		1
2		1
3	20.5 inches rod	2
4		1
5 Spare Parts	39.4 inches chain	2