

A&A Surfaces Glue-Down LVT Care and Maintenance

Maintenance:

- Sweep regularly, with a soft bristle broom.
- Use felt protectors under heavy pieces of furniture and chairs.
- Use protective mats at all exterior entrances. Do not use mats or area rug cushions constructed of rubber or PVC. Instead use urethane backed products.
- Spiked heels or shoes in need of repair can severely damage your floor.
- Replace hard plastic, metal casters or wheels on furniture with soft rubber casters or by using a protective mat under the casters.
- The sun's UV rays can change the color of your floor.
- Keep animal nails trimmed.
- Protect your floor when using a dolly for moving furniture or appliances. Never slide or roll heavy furniture or appliances across the floor.

**Exterior walk off mats should be routinely maintained to avoid becoming a soil source.*

Note - The suggestions mentioned above are for general practice. In case of a particular project, it is recommended that a professional installer/fabricator/restorer is consulted. It is also recommend that cleaning solutions are tried in an isolated area to check for desired results. A&A Surfaces disclaims any liability towards the use of any care & maintenance products.