


THANK YOU FOR CHOOSING VEIKOUS!
YOU WILL NEVER KNOW
HOW EASILY YOU COULD ENLIGHTEN YOUR LIFE
WITH SUPERIORITY AND PLEASURE
NOW YOU KNOW IT


- FOR MORE COST-EFFECTIVE PRODUCTS.
 VISIT WWW.VEIKOUS.COM.
- IF YOU HAVE ANY PROBLEM.
 E-MAIL US AT CUSTOMERSERVICE@VEIKOUS.COM

Fawn




Take the deer and all accessories out of the package.

Fawn




Use zip tie to connect the deer head with the body, make the 4 feet steady by fixing the wire hook.


Fawn




Assemble the tail and bow as picture shown




Take the deer and all accessories out of the package.




Assemble the deer feet with the body by inserting the wire tubes into the holes located on the body as picture shown.



Connect 2 connectors together, use zip tie to connect the deer head with the body, make the 4 feet steady by fixing the wire hook.




Assemble, tail and bow as picture shown.




Take the deer and all accessories out of the package.

Buck



Assemble the deer feet with the body by inserting the wire tubes into the holes located on the body as picture shown.


Buck




Connect 2 connectors together, use zip tie to connect the deer head with the body, make the 4 feet steady by fixing the wire hook.



Assemble the horns, tail and bow as picture shown.



Use the Three-Plugs End Connector to connect three deers cables together, and connect the other end of the connector cable to the transformer.



Assembly is now complete, light up with the transformer supplier. If using outdoor on a lawn, secure the deers by inserting the 4 lawn stakes through the supports and into the soil.