



Assembling & Using Your Product

Unpack all components carefully. Please check to ensure all parts have been removed from the packaging. Some splashing may occur.

Components:

-

Assembling:

- Connect the vinyl tubing to the water pump from inside the fountain top. Adjust the flow control to the lowest setting to avoid splashing until the fountain is completely assembled.
- Feed the LED light strand through the center of the fountain base. Connect the LED light strand to the transformer.
- Place the fountain top on to the fountain basin.
- Gently pour water into the fountain, being careful not to overflow and cause splashing. Make sure the water completely submerges the pump and the water runs clear during operation. Plug the transformer and pump cord into your local power supply. Make sure that there is no water around the transformer and always keep the power source in a dry place.
 - NOTE: We recommend that you use distilled water to prevent scale build-up. The first time you operate the pump it can take up to 5 minutes for the air to be completely expelled and water begins to flow properly.

