

TROUBLESHOOTING

PROBLEM	CORRECTION
The inflation speed is slow.	☐ Check whether the air hose is leaking. ☐ Check the end of the air hose is securely connected. ☐ Check whether the inflated item is leaking.
The inflator turns on but does not inflate.	☐ Check whether the current air pressure is higher than the preset value.
The preset pressure cannot be increased or decreased.	Make sure the air compressor is set to the correct inflation mode. Manual mode allows you to adjust the preset value within a range of 3–150 psi.
The inflator inflates normally but the displayed pressure is zero.	The pressure of low-pressure inflatables including balloons is too low to measure.
The inflator has already turned off after connecting the air hose to a valve.	Please ensure that both the car accessory plug and the power cord port are properly powered and securely connected.
The air leaks out when connecting the air hose.	Make sure the air hose is securely connected.

HUSKY LIMITED TWO-YEAR WARRANTY

If this Husky product ever fails due to a defect in material or workmanship, return the product to any Home Depot retail store for replacement with an item of equal or greater value. This warranty excludes incidental/inconsequential damages and failures due to misuse, abuse or normal wear and tear. This warranty gives you specific rights, and you may also have other rights, which vary from state to state.

Contact the Customer Service Team at 1-888-HD-HUSKY or visit www.HUSKYTOOLS.COM.