



Maintenance

1. Please clean the dispenser by dry towel only. Do not immerse the sanitizer dispenser in water or clean it under running water, this will lead to short circuit.
2. Use only fresh new liquid or gel sanitizer and clean the sanitizer container properly before each re-fill. Deposits of old sanitizer will lead to malfunction and jamming
3. This is an indoor product do not expose under the sunlight.
4. Please take out battery and pour out sanitizer when not in use for a long time.
5. Should the dispenser be out of order, and the batteries have been replaced do not attempt any repair work. Call your dealer for professional assistance.
6. Ensure no bright source is aimed or reflected at the sensor from below.

Warranty

Automatic liquid or gel sanitizer dispenser is warranted to be free from defects in workmanship and material under normal usage from the date of purchase for a period of 1 year.

Specifications

Sanitizer Tank Capacity {fl. oz. (ml)}: 33 (1000)

Battery Life Estimated: 90,000 cycles or 1 year

Troubleshooting Problem Symptom

No sanitizer dispensed on hands

Low Volume sanitizer dispensed

Battery LED indicator flashes

Sanitizer leaks at bottom of housing

Solution Diagnostic

- Check sanitizer qualities, properties and level in reservoir.
- Check sensor cover for dirt obscuring the lens.
- Check battery charge level.
- Check for reflected sensor signals jamming detector.
- Check spout nozzle, cap air hole and valve tube for clogs.
- Remove sanitizer container and wash out spout nozzle, cap air hole and valve tube and replace with fresh new soap.
- Replace batteries
- Contact seller