

BBC72 PARTS DIAGRAM

1	Bolt M10*30		58	Pulley 36.5		115	Tank front securing plate
2	Upper discharge welded		59	Washer 8		116	Bolt M8*12
3	Plastic8		60	Belt B1219		117	Feed inlet rubber baffle strip
4	Middle discharge welded		61	Extension spring		118	Pin 8*45
5	8 spring		62	Bolt M8X25		119	Feed inlet rubber damper
6	Key 8*10*35		63	Roller Puelly		120	Key 9.5*9.5*85
7	Blade		64	Belt cover inner plate		121	Bolt M14*145
8	Quick bolt removal M8		65	Belt cover inner plate gasket		122	BBC plate
9	Lower discharge		66	Nut M12		123	logo plate
10	Bolt M8*245		67	Dust cap		124	Bolt M10*16
11	Nut M10x1.5		68	slotted nut		125	Bolt M10*30
12	Washer 16		69	Washer 26*45*3		126	Bolt M10*55
13	Front axle cover		70	Washer M14		127	Bolt M12*25
14	Spring 10		71	Tire16.5X6.5-8		128	Washer12
15	PLastic washer		72	Rear axle		129	Bolt M14*130
16	Spring 16		73	Bearing FC207		130	Bolt M4*12
17	Hinge		74	Drum shaft belt pulley side cover		131	Washer4
18	Front wheel main frame		75	Bolt M10X60		132	Bolt M5*12
19	Towing frame front frame		76	Lower coaming plate arc plate		133	Bolt M6*70
20	Elastic bolt		77	Mut		134	Lock nut M6
21	Spacer		78	Tire flange		135	Washer 6
22	Bolt M10*170		79	Bolt M14*155		136	Bolt M8*20
23	Bearing		80	Bolt M10X25		137	Bolt M8*30
24	Washer 10		81	Nut14		138	Engine R999
25	Bolt M10X80		82	Frame		139	Engine Key
26	Pin wire B		83	Bolt M10X30		140	Pin ring
27	Pin wire A		84	Limit block stop Angle plate		141	Discharge cylinder rubber cushioning pad
28	Pin		85	Spring14		142	Contact cover plate
29	Bolt M10X60		86	NutM8		143	Drum
30	B Pin		87	Battery box		144	Electric door lock fixed block
31	Tower bar		88	Battery12V20ah		145	Electric door lock lower fixing block
32	Front wheel bracket		89	Spring 12		146	Tool box cover
33	Bolt M5*15		90	Fender guard right		147	Tool box front plate
34	Chain		91	Fender guard left		148	Oil filter side tank support fixing block
35	Tower hitch		92	Bolt M8X70		149	Hour time
36	Buckle		93	Battery layer		150	Hour time fixation
37	Tire 4.1-4		94	lower blade		151	Relief valve
38	Bolt M16X140		95	Battery pressure rubber		152	Feed chute
39	Bolt M5X16		96	Tool cap		153	Feed barrel wiring
40	Fixing block on seat		97	Drum shaft pull start side cover		154	Insulated step mat
41	Bolt M16X160		98	Tool box		155	Engine pulley spacer
42	Block holder (reverse)		99	Buckle 4001		156	Extension nut
43	Front wheel outside spacer		100	Bolt M10*160		157	Plastic buckle
44	Spring retaining sleeve		101	Pressure spring 13 16 115		158	Cable tie
45	Bolt M8X40		102	Pin 2.3*25		159	Towing frame welded body
46	Stuck block		103	Emergency stop switch limit plate		160	Oil nozzle.
47	Card block fixing seat		104	Pin 2.9*36		161	Oil nozzle tank support fixing block
48	Nut M5		105	Quick clip drive arm		162	Bearing cover
49	D Pin		106	Buckle 4001		163	Bolt M10*40
50	Fixing block on seat		107	Spring 4		164	Lock nut16
51	Bolt M6X12		108	Spring 6		165	Guide cover welded body
52	Washer 16X40X3		109	Aluminum rivet 5		166	Bolt M8*16
53	Belt cover welding		110	Quick clip		167	Bolt M8*90
54	5/8-18*40UNF		111	D-pin 6		168	Fuel hose
55	Clutch outer sleeve		112	Bolt M8X25		169	EVBP hose
56	Outer cover word cover piece		113	Oil tank		170	Hoop
57	Washer 8*40*3		114	Emergency stop bar		171	Engine panel welding body