


DOOR HANDING CHART

LH




PUSH AWAY FROM YOU
HINGE ON YOUR LEFT

Hand of door indicates the direction of the swing of the door. It is always viewed from outside the room, building and so forth

Left Hand: Door hinges are on the left when facing the door on the "push" side.

RH



PUSH AWAY FROM YOU
HINGE ON YOUR RIGHT

Right Hand: Door hinges are on the right when facing the door on the "push" side.

ARMOR DOOR™

DRAWN BY:

HP

DATE:

FEBRUARY 06, 2017