



1500W PORTABLE FAN HEATER WITH ADJUSTABLE THERMOSTAT

OWNER'S MANUAL



Model No. VA-301B

IMPORTANT SAFETY INSTRUCTIONS

PLEASE READ CAREFULLY BEFORE USE



CAUTION

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT IMMERSE IN WATER OR ANY LIQUIDS



NEVER COVER APPLIANCE TO PREVENT OVERHEATING FROM OCCURRING

1. DO NOT TOUCH HOT SURFACES. Use handles or knobs.
2. Do not leave the appliance unattended while in operation.
3. Close supervision is necessary when used around children.
4. This appliance is not intended for use by anyone with reduced physical, sensory or mental capabilities, nor by children.
5. Never place flammable objects or clothing on top of the heater.
6. Never use the heater in a room with explosive gas such as butane, or while using any kinds of flammable glues, sprays or solvents.
7. Safely unplug the appliance when not in use or before cleaning. Do not pull the plug out by the cord.
8. The heater must not be directly located below an outlet socket.
9. When in use, allow a 20 inch safe area around the top and side of the heater, and a 50 inch safe area around the front.
10. Do not use in the immediate surroundings of a bath, shower, swimming pool, or any wet environment.

V. PARTS AND LABOR WARRANTY

Vie Air warrants its products to the original purchaser, that are purchased in the USA, for a period of 30 days. Vie air guarantees that this item shall be free from defects in workmanship and materials in their original state and condition, or once reconditioned by Vie Air. Vie Air does not warrant any products that are purchased from an unauthorized dealer.

This warranty is not applicable to any of the following: any items damaged during shipment, any items damaged while in possession of any party other than Vie Air, or any items damaged in use.

In order to have a product services, it must be sent back to Vie Air at the shipper's expense. No COD shipments will be accepted and the cost of shipping is not reimbursed by Vie Air.

Please note that any unit that is sent back to Vie Air must first be authorized for return. In order to receive a mandatory Return Authorization Number, you may contact Vie Air by phone at 1-323-306-3886 or by email at warranty@vieair.com.

In order to ensure accurate processing of any defective units, please ensure that you include the following information with any return:

Your full name, the return address where your items should be sent once refurbished, the best contact number and email address, a detailed account of the defect for which servicing of the unit is being requested, a copy of the original bill of sale, invoice or sales receipt, a list of any other components which were used with the unit being sent back and a description of how they were used, and a check or money order for \$24.99 USD made out to Vie Air, which will be applied to the shipping and handling costs of returning the refurbished unit to the shipper.

All items, once approved to be returned, will need to be shipped to :

Vie Air
Warranty Processing Center
26308 Spirit Court
Santa Clarita, CA 91350

IV. DISPOSING OF YOUR CERAMIC HEATER



Do not dispose of electrical appliances as unsorted municipal waste. Use separate collection facilities.

Contact your local government for information regarding the collection systems available in your area.

If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain which will damage your health and well-being. When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposals free of charge.

11. Do not operate the appliance with a damaged cord, plug or after the appliance has been damaged in any manner. If any part of the appliance is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid hazard.

12. The use of accessory attachments not recommended by the manufacturer may cause injuries.

13. Do not use outdoor.

14. Do not let the cord hang over the edge of any furniture and do not let it touch any hot surfaces.

I. OPERATING YOUR CERAMIC HEATER

****Before operating your heater, ensure that there is a safe area between the heater and any other objects (furnitures, curtains.etc.) Leave at least 50cm (20in) of empty space around the top and sides, and 120cm (50in) around the front.**

To switch on your heater :

1. Turn the right hand-side knob clockwise to the desired heat setting (fan, I or II).

This knob allows you to adjust the power of the heat.

“Fan” : Cool air

“I” : Low heat at 750W

“II” : High heat at 1500W

2. Turn the left hand-side knob clockwise to adjust the thermostat.

To switch off your heater :

1. Turn the right hand-side knob counter-clockwise to “O”.

II. RESETTING AFTER AUTOMATIC SHUT OFF

The VA-301B has a built-in safety device which will automatically switch the heater off in case of overheating.

To reset the appliance:

1. Turn the heater off .
2. Carefully unplug the heater and wait 5-10 minutes for the unit to cool down.
3. After the unit has cooled down, plug it back in and follow the operating instructions.

III. CLEANING YOUR CERAMIC HEATER

- Ensure that the unit is turned off and unplugged before cleaning.
- Ensure that the heater has completely cooled down before cleaning.
- Clean the body of the heater with a damp cloth. DO NOT ALLOW WATER INTO THE APPLIANCE
- Clean the air inlets and outlets regularly with a vacuum cleaner to avoid overheating.
- DO NOT IMMERSE IN WATER OR ANY LIQUID.
- Do not use soap or chemicals which may damage the housing of the heater.
- Allow sufficient drying time before operating again.
- We recommended re-packing your unit in its original packaging , and storing in a cool dry place when not in use.