

Assembly Instructions

Double Salesman Rack

RACK-RCS2



Parts List:

1. Base with upright arms and Casters (x1)
2. Hangbar (x2)
3. Extension Pipes (x4)



1. Remove rack from carton.
2. Place rack on ground and unfold upright arms.



3. Insert extension pipes into upright arms.



4. Insert hang bar on the two upright arms.



6. Extend pull-out extensions if needed.